

# PHILIPS

Vacuum cleaner  
with bag

Performer Active

2100W

AirflowMax technology

EPA 10 filter

Animal

FC8656/01



## Maximum suction power for better cleaning results\*

With AirFlow Max technology and 4L dust capacity

The new Philips Performer Active delivers a better clean thanks to the Airflow Plus technology and the Powerful 2100W motor

### Excellent cleaning results

- Revolutionary Airflow Max technology for extreme suction
- 4L dust capacity for longer cleaning
- 2100 Watt motor generates max. 425 suction power

### Convenience

- Reach all corners thanks to the extra long ergonomic grip

### Integrated Anti-Allergy system

- EPA AirSeal with EPA 10 filter for a healthy air
- S-bag Classic Long Performance lasts up to 50% longer

### Outstanding results on carpets and furniture

- Mini Turbo brush for easy (pet) hair and fluff removal

# Highlights

## Airflow Max technology



Airflow Max technology maximizes the airflow, allowing the dustbag to unfold uniformly, so you get the highest suction power, even as the bag fills-up!

## 4L dust capacity



The specially designed 4L dust chamber allows you to make optimal use of your dust bag, so you can clean for longer.

## Extra long ergonomic grip



This ergonomically shaped grip is convenient in use. Its extra long design gives you farther reach, so you can easily clean hard to reach places.

## EPA 10 AirSeal



EPA 10 Filter and AirSeal capture the finest dust before the air is blown out for a dust-free environment and clean, healthy air.

## S-bag Classic Long Performance



This new Philips synthetic dust bag has been developed to provide long lasting vacuum cleaner performance, i.e. a high level of suction

power and maximum filtration, up to the moment the dust bag is full and ready for disposal.

## Mini Turbo brush



The Mini Turbo Brush quickly removes (animal) hairs, fluff, and dust from couches, cushions, and other fabrics. This brush is ideal for pet owners.

## 2100 Watt motor



2100 Watt motor generates max. 425 suction power for excellent cleaning results.

# Specifications

## Design

**Color:** Sparkle Titanium

## Performance

**Input power (max):** 2100 W

**Input power (IEC):** 1800 W

**Suction power (max):** 425 W

**Vacuum (max):** 34 kPa

**Airflow (max):** 47 l/s

**Noise level (Lc IEC):** 80 dB

## Filtration

**Dust capacity:** 4 L

**Exhaust filter:** EPA 10 filter

**Motor filter:** Microfilter

## Usability

**Action radius:** 9 m

**Cord length:** 6 m

**Tube type:** Metal 2-piece telescopic tube

**Handgrip:** Ergonomic grip with air slider

**Carrying handle:** Front

**Tube coupling:** Conical

**Park or storage assist:** Vertical and horizontal

**Wheel type:** Rubber

## Nozzles and accessories

**Standard nozzle:** Multi-purpose nozzle

**Additional nozzle:** Mini turbo brush

**Accessories included:** Crevice tool, Small nozzle

## Sustainability

**User manual:** 100% recycled paper

## Weight and dimensions

**Weight of product:** 5.2 kg

**Dimensions of product (LxWxH):**  
447x304x234 mm

