

# PHILIPS

Bagless vacuum cleaner

Marathon

2000W

350W suction power

HEPA 13 washable filter



FC9210/01



## Professional cleaning

High cleaning power that lasts and lasts

Thanks to Philips' new Cyclone Filter technology, the Marathon bagless vacuum cleaner delivers suction power that lasts. Its efficient design and 2000 W motor deliver very high max. suction power in its category.

### Thorough cleaning results all the time

- 2000 Watt motor generating max. 350 Watt suction power
- High performance cyclone filter for lasting suction power

### Highly efficient anti-allergy system

- HEPA AirSeal plus HEPA 13 filter

### Easy cleaning, even around furniture

- TriActive nozzle with unique 3-in-1 action

### Extra long reach for convenient cleaning

- More cleaning with less effort

### Filter cleaning system

- Cleaning the filter manually

# Highlights

## Powerful and quiet motor

The Marathon's powerful 2000 Watt motor generates very high max. suction power in its category. Its efficient design makes it also exceptionally quiet.

## HEPA AirSeal, HEPA 13 filter



This Philips vacuum cleaner has been designed in such a way that all the air taken in is passed through the washable HEPA 13 filter (99.95% filtration) before it is exhausted. No escape is possible.

## TriActive nozzle



The TriActive nozzle cleans your floor in 3 ways in one go: 1) A larger opening at the tip of the nozzle easily sucks up big bits. 2) It has maximum cleaning efficiency due to optimized airflow through the nozzle. 3) The two side brushes sweep up the dust and dirt closely alongside furniture and walls.

# Specifications

## Design

Color: Black

## Filtration

Exhaust filter: Ultra Clean Air HEPA 13 washable filter

HEPA AirSeal

Dust capacity: 2 L

## Nozzles and accessories

Accessories included: Crevice tool, Small nozzle

Accessory storage: On handgrip

Standard nozzle: TriActive nozzle

## Performance

Airflow (max): 40 l/s

Input power (IEC): 1800 W

Input power (max): 2000 W

Noise level (Lc IEC): 76 dB

Suction power (max): 350 W

Vacuum (max): 30 kPa

## Usability

Carrying handle: Top and front

Tube coupling: Button

Power control: Electronic on appliance

Tube type: Metal lacquered 2-piece telescopic tube

Wheel type: Rubber

Action radius: 10 m

Cord length: 7 m

## Weight and dimensions

Weight of product: 7.2 kg

