

PHILIPS

Kettle

Daily Collection

Metal

Spring lid

Light indicator

1.7 l



HD9350/92



Designed to last

For long and reliable daily use

Durable kettle in safe, food-grade stainless steel for long and reliable daily use. Philips brings 60 years of trust and expertise to this elegant long-life kettle.

Fast, safe boiling

- Durable stainless steel body for long life
- Micro-mesh filter captures tiny limescale particles
- Flat heating element for fast boiling
- Multi safety system against boil-dry

Simple to fill, use and clean

- Pilot light indicates when the kettle is switched on
- Easy-to-read water level indicator
- Spring lid with large opening for cleaning
- Easy refilling through lid or spout
- Cordless kettle with 360° pirouette base
- Cord winder for easy adjustment and storage

Highlights

Stainless steel design

Durable metal design in food-grade brushed stainless steel for long-term, reliable use.

Micro-mesh filter



A removable micro-mesh filter on the spout captures tiny limescale particles as small as 200 microns to ensure a clear cup.

Flat heating element



A concealed stainless steel heating element ensures fast boiling and easy cleaning.

Multi safety system



Multi safety system against boil-dry, with auto-switch off when the water is ready.

Pilot light



Elegant indicator light incorporated in the power switch illuminates when the kettle is turned on.

Water level indicator



The water level is easy to read with an indicator located underneath the handle.

Spring lid with large opening*



The push-button lid opens smoothly at the touch of a button, avoiding steam contact. The large opening simplifies cleaning.

Easy refilling



The kettle can be filled through the spout or by opening the spring lid.

Cordless + 360° pirouette base



The cordless kettle sits on a 360° pirouette base for easy lifting and replacing.

Hidden cord winder



The cord can be wrapped underneath the base, so it's the right length for any kitchen and easily stored away.

Specifications

General specifications

Product features: 360-degree base, Automatic shut-off, Boil-dry protection, Cord storage, Flat heating element, Non-slip feet, On/off switch, Pilot light, Spring lid, Wide opening lid
Cordless
Easy spout filling
Ergonomic grip
Lid as well as spout filling

Service

2-year worldwide guarantee

Sustainability

Packaging: > 90% recycled materials
User manual: 100% recycled paper

Technical specifications

Cord length: 0.75 m
Frequency: 50/60 Hz
Power: 1850–2200 W
Voltage: 220–240 V
Capacity: 1.7 l

Weight and dimensions

Micromesh filter: 200 µm
Dimensions of packaging (L x W x H): 198 x 228 x 244 mm

Design

Colour: Stainless steel

Finishing

Material of main body: Stainless steel
Material power switch: Polypropylene (PP)

