



Saeco Xsmall
Super-automatic
espresso machine

- 3 Beverages
- Classic Milk Frother
- Black



HD8645/01

Taste the aroma of your favourite coffee beans

100% ceramic grinders for long-lasting performance

Whatever blend of coffee you wish to try next, the Xsmall will grind the beans fresh on the spot at the touch of a button. It comes also equipped with a manual frother to add a touch of velvety pleasure to all your fresh coffee drinks.

A variety of coffees customized to your taste

- Enjoy 3 beverages at your fingertips
- Delicious milk froth thanks to the classic milk frother
- Adjust the length and 5 grinder settings
- Adjust and store your personal user profile
- Enjoy 2 cups at the same time with Double Cup function

Your fresh coffee experience

- 20,000 cups of finest coffee with durable ceramic grinders
- Hot coffee from the first cup with Thermoblock
- Always the right strength in cup, no matters which beans

Enjoy your coffees every day with no hassle

- Fits any kitchen thanks to the small size and frontal access
- Enjoy a great coffee with Auto-Rinse & guided descaling
- Thorough cleaning thanks to fully removable brewing group

PHILIPS

Saeco, a Philips brand



Highlights

100% ceramic grinders



Our grinders are made of high-tech ceramic: exceptionally hard and precise. Fresh beans are gently ground, without risk of overheating: extracting all the best flavors and aroma, delivering a superior coffee taste for at least 20,000 cups.

3 beverages



Enjoy your favourite drinks for your special moments. Whether you crave for an espresso, a coffee or a milk based recipe, your Super-automatic machine delivers a perfect in-cup result with no hassle and in no time!

Auto-Rinse & Guided descaling



This espresso machine automatically cleans its coffee circuit with water upon starting up or

switching off of the machine, this delivers a great, fresh taste with each cup of coffee. Regular descaling prolongs your espresso machine's life. This machine will prompt when descaling is needed. It will guide you with on-screen messages what you have to do and when.

Classic milk frother



The Classic Milk Frother, which baristas also call Pannarello, dispenses steam to help you easily prepare soft milk foam for your cappuccino. Unleash your inner barista by preparing your delicious milk specialties the traditional way!

Customize your coffees

Adjust the length and 5 grinder settings

Double Cup

Enjoy and share your favorite coffee thanks to the double cup function

Gusto perfetto

Gusto Perfetto is self learning technology that tracks constantly the beans you use to prepare your drinks. If it detects a change in the type of beans used, it automatically adjust the dosing in the brew chamber to always ensure a consistent result in cup

Thermoblock



Say goodbye to lukewarm coffee. Thermoblock ensures a hot coffee and cappuccino for you family from the first cup, in no time. The secret is in its light aluminum and stainless steel body, which can reach hot temperatures, fast.

Removable brew group



The brewing group is the heart of every super-automatic coffee machine, and should be cleaned regularly. The fully removable brewing group allows you to clean it thoroughly just by rinsing it under the tap

Small size and frontal access

It doesn't matter how big your kitchen is: this machine fits even the smallest spaces, and it is extremely convenient as you can access the water and waste containers from the front. Designed for making your coffee enjoyment easier.

User Profiles

Store the length of any coffee beverage according to your personal taste. You will be able to drink espresso, coffee and all other beverages always as you prefer, at the touch of a button.

Specifications

General specifications

- Milk Solution: Classic Milk Frother
- User Interface: LED Buttons

Technical specifications

- Capacity waste container: 8 servings
- Capacity water tank: 1 L
- Coffee bean capacity: 180 g
- Cord length: <100 cm
- Filter compatibility: Brita Intenza
- Frequency: 50 Hz
- Max. cup height: 95 mm
- Product dimensions: 295 x 325 x 420 mm
- Voltage: 230 V
- Waste container: Frontal access
- Water tank: Frontal access

Customization

- Aroma Strength Settings: No

- Coffee Length: Adjustable
- Grinder Settings: 5
- Pre Brew Aroma control: No
- User Profiles: 1

Other features

- Auto-Rinse & Guided descaling
- Gusto perfetto
- Main Switch ON / OFF button
- Quick Heat Boiler
- Removable brew group

Variety

- Beverages: Espresso, Espresso Lungo, Hot water
- Coffee Powder Option: No
- Double Cup
- Milk Double Cup: No