

# PHILIPS

Bagged Cylinder Vacuum Cleaner, Anti-Allergen

Performer Active

3in1 nozzle for maximum dust pick up

AirflowMax technology

FC8578/69



## Full performance, low energy consumption Hygienic cleaning with AirflowMax

The Philips Performer vacuum cleaner delivers top cleaning performance with low energy consumption. Keep the air in your home clean and healthy too thanks to our Allergy Filter, which traps 99.9%+ of harmful particles.

### Remarkable cleaning results

- Revolutionary AirflowMax technology for strong suction power
- New 3-in-1 TriActive+ nozzle picks up coarse and fine dust
- Turbo brush, perfect for homes with pet hair

### Maximum convenience

- Integrated brush for ultimate convenience
- ActiveLock couplings to easily adjust to each cleaning task
- Soft bumper toe ensure easy gliding along furniture and walls
- 4 l dust capacity for longer cleaning

### Hygienic cleaning

- Allergy filter captures more than 99.9% of fine dust
- s-bag Classic Long Performance lasts up to 50% longer
- ECARF allergy-friendly quality tested



# Highlights

## AirflowMax technology



The unique AirflowMax technology keeps the suction power stronger for longer\* to use the bag to the very end. The technology is built around the optimisation of three key elements: 1) Unique ribs profile inside the dust chamber to maximise airflow around the dustbag and enable the use of the entire bag surface. 2) Specially designed dust chamber capacity that allows the dustbag to fully unfold uniformly. 3) High quality, non-clogging fibre structures in the dustbag absorb dust without blocking the pores, which helps to avoid the reduction of suction power.

## TriActive+ nozzle



The TriActive+ nozzle applies 3 cleaning actions in one go: 1) It gently opens the carpet with its specially designed soleplate to remove the dust deep down. 2) It sucks up bigger bits of dirt with its larger opening at the front. 3) It sweeps up the dust and dirt alongside furniture and walls with its two side brushes.

## Turbo brush



The Turbo brush allows deep cleaning of carpets, easily removing hair and fluff. The rotating brush inside the nozzle actively removes small dust particles and pet hair, resulting in a better cleaning performance.

## Integrated Brush



The vacuum cleaner is designed with integrated accessories, so that you do not need to carry extra pieces around while you clean. The soft dusting brush is conveniently integrated in the handle of the appliance so it's always ready to use.

## ActiveLock couplings



The ActiveLock couplings allow you to easily connect and disconnect the different nozzles and accessories from the telescopic tube while cleaning.

## Soft bumper



The soft bumper protects furniture and prevents damage if you accidentally bump into your furniture or walls and stops it from getting stuck on edges, so you can move around faster.

## 4 l dust capacity



The specially designed 4 l dust chamber allows you to make optimal use of your dust bag, so you can clean for longer.

## Allergy filter



Developed to meet the specific needs of allergy sufferers and more generally of people demanding a higher level of hygiene.



## 5-year warranty

Register at [philips.com/welcome](https://philips.com/welcome) within 3 months of purchase to enjoy 5-year warranty on the motor for free!

# Specifications

## Performance

**Airflow (max):** 32.17 l/s  
**Input power (IEC):** 650 W  
**Sound power level:** 77 dB  
**Vacuum (max):** 17.5 kPa

## Usability

**Action radius:** 9 m  
**Carrying handle:** Front  
**Cord length:** 6 m  
**Tube type:** Metal 2-piece telescopic tube  
**Wheel type:** Rubber  
**Tube coupling:** ActiveLock  
**Power control:** Rotary knob

## Design

**Colour:** Deep Black

## Filtration

**Dust bag type:** s-bag Classic Long Performance  
**Dust capacity:** 4 l  
**Exhaust filter:** Micro filter  
**Motor filter:** Micro filter

## Nozzles and accessories

**Accessories included:** Crevice tool, Integrated brush  
**Additional nozzle:** Hard floor nozzle, Turbo brush  
**Standard nozzle:** TriActive+ nozzle

## Sustainability

**Packaging:** > 90% recycled materials  
**User manual:** 100% recycled paper

## Weight and dimensions

**Dimensions of product (LxWxH):** 447 x 304 x 234 mm  
**Weight of product:** 5.2 kg

