



Gaggia
Super-automatic
espresso machine

• Gaggia Accademia

RI9702/01



BECOME A REAL BARISTA WITH ACCADEMIA GAGGIA

DELIGHT OF USING A MASTERPIECE OF TECHNOLOGY

An Espresso per favore! No wait a cappuccino or a latte macchiato...Gaggia Accademia offers you all the secrets of a professional Barista in just one touch, at home. Every day you will taste a traditional Italian Espresso...and much more!

Tradizione...

- Durable ceramic grinder for pure coffee aroma
- Stainless steel body for long-lasting performance
- Double boiler to reduce waiting time
- Pre-brewing for flavor enhancing

...in continua evoluzione

- Easy cleaning thanks to removable brewing group
- Always a clean machine thanks to automatic circuit cleaning
- Digital display for easy navigation
- Adjust your Espresso to fit your taste
- Efficient cup warmer for a hot Espresso
- One touch operation

GAGGIA
MILANO

HIGHLIGHTS

Durable ceramic grinder



Because a metal grinder might burn the coffee beans while grinding, all Gaggia's Espresso machines are equipped with an extremely durable ceramic grinder. A ceramic grinder will retain the purity of the coffee aroma while being equally durable to a metal grinder. Additionally the coffee grind can be adjusted from coarse to fine, just as you prefer.

Adjust your Espresso



The settings in this Gaggia Espresso machine allow you to adjust the body and aroma of your coffee to suit your taste, while maintaining a perfect crema.

Cup warmer



Your Gaggia Espresso machine has an energy-efficient integrated heating element to provide

pre-warmed coffee cups. Pre-warming a cup will ensure your Espresso stays hot for longer.

Pre-brewing



Pre-brewing ensures that the ground coffee is evenly moistened before the actual brewing process. Only then the water flows through all of the ground coffee and your Gaggia Espresso machine can extract the full aroma for a balanced and tasty Espresso.

Stainless steel body



The case of your machine has been skillfully manufactured from stainless steel. This makes your Gaggia more robust, ensures long-lasting performance and is an eye-catcher in every kitchen.

Digital display



Whatever you want to do with your Gaggia - the digital display makes navigation much easier and gives instant feedback on the status of your Espresso machine.

One touch operation



Just press one of the 7 pre-set beverages and your Gaggia Espresso machine will brew them in a few seconds.

Removable brewing group



The removable brewing group in your full-automatic Espresso machine allows for easy cleaning and maintenance and can even be replaced separately if necessary. This saves money and increases the machine hygiene for a flawless coffee taste.

SPECIFICATIONS

Technical specifications

- Number of water boilers: 1 boiler
- Supported coffee types: Ground coffee, Whole coffee beans

Service

- 2-year worldwide guarantee

Weight and dimensions

- Product dimensions: 38.5 x 28.2 x 42.8 cm
- Coffee bean capacity: 350 gr
- Waste container capacity: 16 servings
- Milk carafe capacity: 0,6 L
- Product weight: 17 kg
- Water tank capacity: 1,6 L
- Maximum cup height: 150 mm

Features

- Brita Filter compatible
- Cupholder
- Hot water / Steam Nozzle

Energy saving

- Energy saving: Automatic stand-by

Design

- Colour: black/stainless steel
- Materials and finishing: metal painted/stainless steel

Technical data

- Boiler: Stainless steel
- Frequency: 50 Hz
- Power: 1500 W
- Pump Pressure: 15 bar
- Voltage: 230 V