

PHILIPS

Vacuum cleaner
with bag

Expression

HomeCare

FC8611/01



Gives dust no chance

Multiple filters trap up to 99.9% of all dust

The Philips Expression vacuum cleaner with bag offers an effective way of filtering pollen, spores, and allergens out of the air. The washable HEPA 12 filter, in combination with the s-bag Clinic, traps up to 99.9% of all dust particles.

High cleaning power

- 1800 Watt motor generating max. 350 Watt suction power

Clean air in your home

- Washable HEPA 12 filter, 99.5% filtration

Hygienic disposal of dust bag

- Unique Clean Comfort Cassette to avoid contact with dust

Dust bag safely traps all dust

- s-bag Clinic catches up to 99.9% of all dust

Highlights

1800 Watt motor



1800 Watt motor generating max. 350 Watt suction power for perfect cleaning results.

Washable HEPA 12 filter



This washable HEPA 12 filter catches at least 99.5% of all harmful microscopic vermin that causes respiratory allergies.

s-bag Clinic - Anti-allergy



This dust bag filters up to 99.9% of pollen, spores and allergens. Ideal for people with allergies!

Clean Comfort Cassette



When disposing the dust bag, there will be no contact with the dust thanks to this patented dust bag holder.

Specifications

Design

Color: Raven black

Filtration

Dust bag type: s-bag Clinic Anti-allergy

Dust capacity: 3 l

Exhaust filter: Super Clean Air HEPA 12 washable filter

Motor filter: Triple layer

Nozzles and accessories

Accessories: Crevice tool, Small nozzle

Accessory storage: On tubeclip

Standard nozzle: All-purpose nozzle

Performance

Airflow (max): 40 l/s

Input power (IEC): 1600 W

Input power (max): 1800 W

Noise level (Lc IEC): 82 dB

Suction power (max): 350 W

Vacuum (max): 30 kPa

Usability

Action radius: 10 m

Carrying handle: Front

Clean Comfort cassette

Cord length: 7 m

Coupling: Conical

Dust bag full indicator

Power control: Electronic on appliance

Tube type: Metal lacquered 2-piece telescopic tube

Wheel type: Plastic

