

Bagless vacuum cleaner

# **PowerPro**

2000W

PowerCyclone 5

HEPA 10 washable filter



FC8760/61



# Effortless cleaning, powerful performance

# With PowerCyclone technology

The new Philips PowerPro effortlessly cleans your floors thanks to the PowerCyclone 5 technology. The advanced dust container is easy to empty and helps avoiding dust clouds.

# **Powerful cleaning performance**

- ${}^{\textstyle \bullet}$  PowerCyclone 5 technology separates dust and air in one go
- · 2000 Watt motor for high performance

# Extra long reach for convenient cleaning

· More cleaning with less effort

# Easy to clean

- Advanced dust container design for hygienic emptying
- · Washable foam filter for life-long performance

# Highlights

## **PowerCyclone 5 Technology**



PowerCyclone 5 technology maximizes airflow and performance by separating dirt from air in one go. It delivers remarkable cleaning results through highly efficient steps: 1) Air enters fast into the PowerCyclone thanks to the air inlet design. 2) The curved airpass quickly accelerates the air in the cyclonic chamber to separate the dust from the air. 3) The optimized exit blades separate dirt from the cyclone and into the dust bucket.

#### 2000 Watt motor



The 2000 Watt motor generates max. 360 Watt suction power for high performance.

# Easy to empty dust container



The dust container is carefully designed to dispose collected dirt without creating a dust cloud. It is one-hand operated and thanks to its unique shape and smooth surface, you can easily control the emptying of the dust container.

#### Life-long washable foam filter



The foam filter can be easily washed under the tap for life-long performance.

# 10 m action radius



10 m action radius for cleaning with less effort.

# Specifications

### Design

Color: Juicy red

#### Performance

Input power (max): 2000 W Input power (IEC): 1800 W Suction power (max): 360 W Vacuum (max): 33 kPa Airflow (max): 37 l/s Noise level (Lc IEC): 80 dB

#### **Filtration**

Dust capacity: 2 L Exhaust filter: EPA 10 filter Motor filter: Lifetime washable filter

**HEPA Air Seal** 

## **Usability**

Action radius: 10 m Cord length: 7 m

Tube type: Metal 2-piece telescopic tube

Carrying handle: Top and front Tube coupling: Easy release Wheel type: Rubber

Power control: Electronic on appliance

# Nozzles and accessories

Standard nozzle: Wheeled all-purpose nozzle Accessories included: Crevice tool, Small

nozzle

Accessory storage: On tubeclip

## Sustainability

Packaging: > 90% recycled materials User manual: 100% recycled paper

# Weight and dimensions

Weight of product: 5.5 kg

Dimensions of product (LxWxH): 440 x 300 x

290 mm

© 2019 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

Issue date 2019-03-15 Version: 6.1.1

