

Philips PerfectCare Viva  
Refurbished Steam  
generator iron

**Refurbished product**

Max 6 bar pump pressure  
Up to 340 g steam boost  
Compact design with a 2-l water  
tank capacity

**GC7055**



## Iron faster with 2 x more steam \*

no temperature setting required

Philips steam generator iron delivers a faster and easier ironing experience. Iron your garments with no temperature adjustment needed thanks to the revolutionary OptimalTEMP technology.

**No temperature setting needed; no burning, guaranteed**

- Go from ironing jeans to silk; no need to change temperature setting
- Safe to leave the hot soleplate on the ironing board

**Fast ironing with continuous powerful steam**

- Integrated easy-clean system for long-lasting performance
- Philips' best gliding with increased scratch resistance
- Save energy with ECO mode
- Powerful steam for ultimate crease removal

**Compact technology**

- Lightweight and compact size for easy storage
- Large water tank for longer continuous use
- Safe and secure carry lock
- Automatic switch-off for safety and energy saving

**PHILIPS**

## Refurbished Steam generator iron

Refurbished product Max 6 bar pump pressure, Up to 340 g steam boost, Compact design with a 2-l water tank capacity

GC7055/20R1

# Highlights

### OptimalTEMP technology



With OptimalTEMP technology you'll no longer have to waste time changing temperature settings, waiting for the temperature to adjust or pre-sorting clothes. Iron all fabrics, from jeans to silk, with no burning guaranteed thanks to the perfect combination of temperature and continuous powerful steam.

### Safe rest



Innovative OptimalTEMP technology guarantees no burning on any ironable fabric. As well as the reassurance this provides whilst ironing, it also means you can leave the hot iron soleplate directly on your cotton ironing board without causing any damage. This helps to reduce any discomfort to your wrists, as you won't need to lift the iron to and from its base as often.

### Smart Calc clean



Regular descaling protects your iron and maintains steam performance. The Smart Calc-Clean system is an integrated descaling and cleaning function to extend the lifespan of your steam generator iron. The iron will remind you with both light and sound that cleaning and descaling is needed. Simply place your iron onto the Smart Calc-Clean container and start the process. It takes approx. 2 minutes for the dirty water and scale to be collected; your steam generator will beep once it's finished and ready to use again.

### SteamGlide Plus soleplate



The SteamGlide Plus soleplate is durable and non-stick because of the ceramic finishing. It has an integrated titanium oxide layer for superior gliding performance.

### Energy saving



ECO mode allows you to save energy without compromising your ironing results. The ECO mode uses a reduced amount of steam, but still a sufficient amount to iron all your garments.

### Ultra-powerful steam



An ultra-fast ironing experience can be yours with revolutionary technology. The powerful and continuous steam tackles even tough creases, and thicker fabrics are smoothed out with ease and speed. Plus there's an extra steam boost if needed, perfect for vertical steaming or stubborn creases.

## Refurbished Steam generator iron

Refurbished product Max 6 bar pump pressure, Up to 340 g steam boost, Compact design with a 2-l water tank capacity

# Specifications

### Technology

- For all ironable fabrics
- No burns
- No temperature settings needed
- OptimalTEMP technology
- ProVelocity steam engine
- Smart Control Processor

### Fast crease removal

- Continuous steam: up to 120 g/min
- Power: 2400 W
- Pressure: Max 6 bar pump
- Ready to use: 2 min
- Steam boost: up to 340 g
- Steam-on-demand
- Variable steam levels
- Vertical steam
- Voltage: 220 - 240 V

### Easy to use

- Safe on all ironable fabrics: Even delicates like silk
- Soleplate gliding performance: 5 stars
- Soleplate name: SteamGlide Plus
- Cord freedom (swivel): 360 degree cord freedom
- Hose length: 1.6 m
- Power cord length: 1.8 m
- Ready to use: Light indicator, Sound indicator

- Refill anytime during use
- Safety auto off
- Soleplate scratch resistance: 4 stars
- Tap water suitable
- Heat-up time: 2 min
- Extra-large filling hole

### Scale management

- Descaling and cleaning: Smart Calc Clean
- Descaling reminder: Light, Sound, Yes, no cartridges needed, no extra

### Storage

- Carry lock: For transportation and safety
- Cord storage: Velcro fix
- Hose storage: Hose storage compartment

### Accessories included

- Calc clean container

### Size and weight

- Packaging dimensions (W x H x D): 42.7 x 23.8 x 33.5 cm
- Product dimensions (W x H x D): 32.2 x 19.4 x 23.6 cm
- Weight of iron: 1.2 kg
- Weight of iron + base: 4.1 kg



Issue date 2019-12-04

Version: 1.0.1

12 NC: 0000 041 01940  
EAN: 87 10895 68308 1

© 2019 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* Compared to Philips steam iron EasySpeed