

PHILIPS

Bagless vacuum
cleaner

HomeCare



FC8262/01



Keep it out of sight!

Ultra-compact, with storage box

Thanks to its ultra-compact design, this vacuum cleaner is lightweight and easy to store away. A convenient plastic storage box neatly stores the vacuum and cleaning accessories after use. The cyclonic dustbin saves the use of a dust bag.

Multiple storage solution

- Durable and hygienic plastic box

No dust bag required

- Cyclonic dustbin 1 litre

High cleaning power

- 1600-Watt motor generating 300 Watts max. suction power

Ease of use

- Telescopic metal tube

The right suction power for every surface

- Electronic power control

Highlights

Durable and hygienic plastic box



The tailor-made storage box has a partition to store the hose and a tray to store the nozzle, tube and accessories above the vacuum cleaner. Other cleaning equipment, such as cloths, sprays etc., can be stored inside as well. The box has a flat cover to allow storage of other things on top.

Cyclonic dustbin 1 litre



Cyclonic dustbin 1 litre

HEPA filter



This HEPA filter catches harmful microscopic vermin that cause respiratory allergies. To maintain effective filtration, replace the HEPA filter every 6 months.

Specifications

Design

Colour: Striking purple

Filtration

Dust capacity: 1 l

Exhaust filter: HEPA washable filter

Nozzles and accessories

Accessories included: Crevice tool, Small nozzle

Accessory storage: In plastic storage box

Standard nozzle: All-purpose nozzle

Performance

Airflow (max): 32 l/s

Input power (IEC): 1400 W

Input power (max): 1600 W

Noise level (Lc IEC): 85 dB

Suction power (max): 250 W

Vacuum (max): 28 kPa

Usability

Action radius: 8 m

Carrying handle: Top and front

Cord length: 5 m

Tube coupling: Conical

Power control: Electronic on appliance

Tube type: Metal 2-piece telescopic tube

Wheel type: Plastic

Weight and dimensions

Weight of product: 3.7 kg

