

# PHILIPS

Pressurised steam generator

7400 series

4.5 bar

ECO

GC7420/02



## Fast and powerful ironing

Iron with 2-min quick start, refill any time

Created to speed up ironing from start to finish, the Philips iron 7400 series is ready in 2 minutes. Pressurised steam power speeds up ironing by penetrating deeper into fabric and the large water-filling inlet allows fast and easy refills

### Fast and powerful ironing

- Up to 4.5 bars of steam pressure for fast ironing
- Continuous steam up to 120 g/min
- Vertical steam for crease removal in hanging fabrics

### Comfortable ironing

- Lightweight iron for effortless ironing
- SteamGlide soleplate is Philips premium soleplate

### Easy to use

- Start quickly: less than 2 minutes start-up time
- Refill the water tank at any time, even during ironing
- Permanent anti-calc tablets inside delay scale build up

## Highlights

### Continuous steam up to 120 g/m



The Philips iron has a continuous steam output of up to 120 g/min thanks to the small amounts of water that are pumped into the boiler each time. For perfect and fast crease removal.

### SteamGlide soleplate



The SteamGlide soleplate is the best Philips soleplate for your steam iron. It has great scratch resistance, glides excellently and is easy to clean.

## Specifications

### Fast and powerful crease removal

Soleplate: SteamGlide

Steam output

Continuous steam output: 120 g/min

Vertical steam

Steam pressure: Up to 4.5 Bar

Steam tip

Power: 2400 W

### Easy to use

Water tank capacity: 1000 ml

Filling and emptying water: Extra large filling hole

Refill any time

Heat-up time: 2 min

Hose storage: Hose clip

Power cord length: 1.8 m

Cord freedom (swivel): 180 degree cord freedom

Hose length: 1.7 m

### Calc management

Suitable for tap water

Calc clean solution: Anti-calc tablets and rinsing

### Technical specifications

Voltage: 220 - 240 V

Product dimensions: 42.9 x 40 x 20.6 cm

Weight of iron: 1.2 kg

Weight of iron + base: 4.5 kg

