



**Saeco PicoBaristo
Super-automatic
espresso machine**

- 8 Beverages
- Automatic Milk Frother
- Stainless steel
- 10-step adjustable grinder



HD8924/47

The largest variety from a compact machine

Enjoy 5000 cups of divine coffee without descaling

PicoBaristo is a premium compact machine which spoils coffee lovers for variety. Via the user interface you can choose from a wide choice of specialties at one touch. And with the AquaClean filter you can enjoy 5,000 cups* without descaling

Advanced technology designed for coffee perfection

- Velvety froth at one touch with the Automatic Milk Frother
- 20,000 cups of finest coffee with durable ceramic grinders
- Enjoy hot coffee in no time with the Quick Heat Boiler

A variety of coffees customized to your taste


- A multitude of specialty coffees at the touch of a button
- The strength selection remembers just how strong you like it
- Fine-tune the coffee's richness with 10 grinder settings

High comfort is part of the experience

- Up to 5000 cups* without descaling with AquaClean filter
- Iconic stainless steel front, shaped to precision
- Tactile backlit display and seamless navigation

PHILIPS

Saeco, a Philips brand



Highlights

AquaClean filter



AquaClean

Saeco's new and patented innovation, AquaClean water filter, ensures you make the most out of your full automatic coffee machine. By changing the filter at machine request, you will not need to descale your machine for up to 5000 cups*, while getting the benefit of clear and purified water. As an added benefit, the descaling notification alarm is automatically deactivated once AquaClean is installed in your favourite Saeco coffee machine.

Quick Heat Boiler



When time is of the essence, you can brew perfect espresso and cappuccino without the wait, thanks to the Quick Heat Boiler. The

secret is in its light aluminum and stainless steel body, which can reach hot temperatures, fast.

Customize your coffee



Choose your ideal strength from the 5 different settings, select the length and the temperature. You can easily save your desired coffee length with the Memo Function for each drink. Then every cup in the future will be customised exactly to your taste. You'll never have to remind it again, unlike the local barista.

100% Ceramic grinders



Our grinders are made of high-tech ceramic: exceptionally hard and precise. Fresh beans are gently ground, without risk of overheating: extracting all the best flavors and aroma,

delivering a superior coffee taste for at least 20,000 cups.

Automatic Milk Frother



The Automatic Milk Frother will deliver your coffee's crowning glory at the touch of a button. Within seconds it will be topped with a silky, milk layer of the finest consistency - the ultimate lure for all cappuccino lovers.

10-settings adjustable grinder



When it comes to the fineness of the grind, this machine never fails to satisfy. Different coffee blends require different levels of granularity for the full flavour to unfold. So the grind granularity of this machine has ten adjustable settings – from the finest grind for a full-bodied espresso, to the coarsest for a lighter coffee.

Specifications

Accessories

- Included: Measuring scoop, Water hardness test strip, Cleaning brush

Design

- Color: Black, Stainless steel

Finishing

- Material boiler: Stainless steel (Inox)
- Material drip tray: Stainless steel
- Material of main body: Stainless Steel front
- Material water tank: Plastic

Country of origin

- Made in: Europe

General specifications

- Coffee strength settings: 5
- Cups at the same time: 2
- Customizing per drink: Adjustable coffee strength, Adjustable cup volume, Adjustable temperature, Memo function cup volume
- Ease of cleaning & maintenance: Automatic descaling cycle, Automatic rinse cycle, Descale indicator, Dishwasher-safe parts, Removable brewing group, AquaClean filter compatible
- Ease of use and comfort: Removable spout, Display, Removable drip-tray, Removable water tank, Automatic shut-off
- Grinder settings: 10
- One touch variety: 11

- Special functions: Automatic milk frother, Ceramic grinder, Hot water option, Ground coffee option, Pre-brewing
- Temperature settings: 3
- Type of display: LCD

Sustainability

- Energy label: A-class
- Power consumption brewing: 1850 W

Technical specifications

- Brewing time one cup: 45 (espresso) to 100 (long coffee) sec
- Capacity bean container: 250 gr
- Capacity waste container: 15 servings
- Capacity water tank: 1.8 L
- Cord length: 1.2 m
- Frequency: 50 Hz
- Max. cup height: 78 - 164 mm
- Voltage: 120 V
- Water boilers: 1
- Pump pressure: 15 bar

Weight and dimensions

- Dimensions of product (WxDxH): 215 x 429 x 330 mm
- Weight of product: 7.27 kg

Service

- 1-year guarantee