



**Saeco Incanto
Super-automatic
espresso machine**

- 6 Beverages
- Integrated milk carafe
- Stainless steel
- 5 step adjustable grinder



HD8917/47

Elegant design. Impressive coffee quality.

Delicious Latte Macchiato at the touch of a button

The Saeco Incanto sets a new standard in its class. The refined, stainless steel front houses high-quality Italian technology, engineered to brew divine coffee, every time. Your coffee dreams have finally been answered.

Advanced technology designed for coffee perfection

- 20,000 cups of finest coffee with durable ceramic grinders
- Enjoy hot coffee in no time with the Quick Heat Boiler
- Delicious hot Cappuccino and Latte Macchiato at one touch
- Fine-tune the coffee's richness with 5 grinder settings

High comfort is part of the experience

- Iconic stainless steel front, shaped to precision
- Auto-cleaning cycle removes any hassle
- The fully removable brewing group can be cleaned in no time

A variety of coffees customized to your taste

- A multitude of specialty coffees at the touch of a button
- Decaffeinated with equal zest with the Powder Option
- The strength selection remembers just how strong you like it

 **Saeco**

PHILIPS

Saeco, a Philips brand



Highlights

100% Ceramic grinders



Our grinders are made of high-tech ceramic: exceptionally hard and precise. Fresh beans are gently ground, without risk of overheating: extracting all the best flavors and aroma, delivering a superior coffee taste for at least 20,000 cups.

Quick Heat Boiler



When time is of the essence, you can brew perfect espresso and cappuccino without the wait, thanks to the Quick Heat Boiler. The secret is in its light aluminum and stainless steel body, which can reach hot temperatures, fast.

Specialty coffees at one touch



From, espresso to Lattemacchiato, there is an assortment of options waiting to satisfy your coffee cravings. Whether it's first thing in the morning or an after dinner treat, there's a taste for any time of the day, right at your fingertips.

Powder Option



Sometimes it's nice to have the option of a full-bodied, delicious coffee, without the caffeine kick. Thanks to the Powder Option you can make decaffeinated coffee whenever you please.

Stainless steel front



Every minute detail of this machine was designed and crafted to the highest quality. The

solid, stainless steel front, vibrant display, and tactile feel of each button are the perfect balance of elegance, intuitiveness and Italian craftsmanship. The Saeco Incanto will grace any modern or traditional kitchen it finds for years to come.

Auto-cleaning



The automatic cleaning cycle makes it easy to look after, and it increases the machine's longevity – giving you more time to enjoy your coffee instead of cleaning up.

One-touch Cappuccino and Latte

For an irresistible, creamy foam consistency, the integrated milk carafe froths the milk twice, removing bubbles and impurities. At one press of a button, a splash-free flow of velvety foam pours straight into your cup at a comfortable temperature. The perfect complement to a rich, flavorsome coffee.

Removable brewing group



Efficiency and ease of use were key inspirations when Saeco invented the first brewing group 30 years ago. And to this day, it still proves to be an inspired, resolute piece of technology. As always, it's so simple to clean – just remove it and wash it under the tap for a few seconds, then re-insert it just as easily.

Specifications

Accessories

- Included: Water filter

Design

- Color: Stainless steel & black

Finishing

- Material boiler: Stainless steel (Inox)
- Material drip tray: Stainless steel
- Material of main body: Stainless steel & plastic
- Material of spout: Plastic
- Material water tank: Plastic

Country of origin

- Made in: Europe

General specifications

- Coffee strength settings: 5
- Suitable for: Whole coffee beans, ground coffee powder
- Cups at the same time: 2
- Customizing per drink: Adjustable coffee strength, Adjustable cup volume, Adjustable temperature
- Ease of cleaning & maintenance: Automatic descaling cycle, Automatic rinse cycle, Automatic carafe cleaning, Removable brewing group
- Ease of use and comfort: Adjustable spout, Automatic stand-by, Display, Removable drip-tray, Removable water tank, Automatic shut-off
- Grinder settings: 5
- One touch variety: 6
- Special functions: Ceramic grinder, Hot water option, Integrated carafe, Ground coffee option,

Pre-brewing

- Temperature settings: 3
- Type of carafe: Basic carafe
- Type of display: LCD
- Coffee drinks: Espresso, Espresso Lungo, Cappuccino, Latte Macchiato, Hot Water, Milk Froth
- Milk Solution: Integrated Milk Carafe

Sustainability

- Power consumption brewing: 1850 W

Technical specifications

- Brewing time one cup: 45 (espresso) to 100 (long coffee) sec
- Capacity bean container: 250 gr
- Capacity milk carafe: 500 L
- Capacity waste container: 15 servings
- Capacity water tank: 1.8 L
- Cord length: 0.8 m
- Frequency: 50 Hz
- Max. cup height: 152 mm
- Pump pressure: 15 bar
- Voltage: 230 V
- Water boilers: 1

Weight and dimensions

- Dimensions of product (WxDxH): 215 x 429 x 330 mm
- Weight of product: 7.2 kg

Service

- 1-year guarantee