PHILIPS

Steam generator iron

PerfectCare Aqua Silence

Up to 6.2 bar pressure

330 g steam boost

Carry lock

2.5-l fixed water tank



GC8651/10



Ultra fast and quiet ironing

with no temperature adjustment required

Iron any ironable garment from silk, to linen, to cotton, to cashmere...in any order, without having to adjust. Your Philips PerfectCare Iron delivers fast results without risk of burn or shine for all your garments. Truly simple ironing.

Carefree ironing, no temperature setting required

- · Silent steam technology: Powerful steam with minimum sound
- Iron everything from jeans to silk with no temperature setting required
- \cdot Safe to leave the hot soleplate on the ironing board
- Tested and approved by independent textile experts

Fast and powerful ironing

- $\boldsymbol{\cdot}$ Descale your appliance effectively and easily to prolong its lifespan
- · Tap water-friendly, refill any time during ironing
- $\boldsymbol{\cdot}$ The safety auto off function automatically switches the appliance off
- · Ready to use in 2 minutes with unlimited refill
- Up to 6.2 bar pressure
- Large 2.5 l fully visible water tank
- · Our best gliding soleplate
- · Saving energy with ECO mode
- · Lock your iron securely to the base station



Highlights

Silent steam technology



Enjoy ironing with family around or while watching TV, without being disturbed by the noise of the steam. Silent steam technology delivers quiet yet very powerful steam. The steam generator is fitted with silencing steam filters to reduce the noise of the steam and a sound-absorbing platform to reduce the noise of the pump in the base.

OptimalTEMP technology



Now you can iron everything from jeans to silk with no temperature setting required.
Guaranteed no burn on all ironable fabrics.
Revolutionary technology with both the Advanced Smart Control Processor, which precisely controls the soleplate temperature so that you don't need to, and the powerful cyclonic steam chamber, which delivers consistent, powerful steam, making ironing easier and faster.

Easy De-calc



Ultra-long-lasting steam performance: Philips' exclusive Easy De-Calc function provides the ideal way to get rid of limescale and extend

the lifetime of your steam generator iron. Your iron will remind you to de-calc with light and sound. When your appliance is cold, simply open the Easy De-Calc knob and collect the dirty water and limescale in a cup.

Energy saving



By using ECO mode and a reduced amount of steam, you can save energy without compromising on the ironing results.

Refill with tap water any time



Your steam generator iron is designed to use tap water. While ironing, when the water tank runs out of water, you can easily refill it without having to wait or turn off your appliance.

Safety carry lock



Your steam generator iron comes with a safety carry lock. You can lock your iron safely on the base, making it safer and reducing the risk of people touching the hot soleplate. You can also carry the steam generator easily.

Safe rest



The innovative Philips OptimalTEMP technology guarantees no burns on all ironable fabrics. During ironing, there is no need to put your iron back on the base station; just leave the hot iron soleplate directly on the garments or cotton ironing board cover without an additional resting accessory. It will not damage any of your ironable garments, or the board. This makes your ironing easier, with less wrist effort.

Safety auto off



The safety auto off function automatically switches off the appliance if it has not been used for 10 minutes, to save energy.



asimpleswitch.com

Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas — Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.

Specifications

Calc management

Calc clean reminder
Calc clean solution: Easy De-calc

Suitable for tap water

Easy to use

Cord freedom (swivel): 180 degree cord

freedom

Cord storage: Cord clip Heat-up time: 2 min Hose length: 1.7 m

Hose storage: Hose storage compartment

Low water alarm
Power cord length: 1.8 m

Refill any time

Safe for all fabrics: Even for delicates such as

silks

Safety auto off

Storage solution: Carry lock Water tank capacity: 2500 ml

Filling and emptying water: Extra-large filling

hole

Fast and powerful crease removal

OptimalTEMP technology

Power: 2400 W

Safe rest

Silent Steam Technology Soleplate: T-ionicGlide Steam boost: 330 g Steam tip

Vertical steaming

Pressure: Up to 6.2 bar pressure

Sustainability

Energy saving mode

Technical specifications

Voltage: 220 - 240 V

Product dimensions: 36.2 x 27 x 26.3 cm

Weight of iron: 1.1 kg

Weight of iron + base: 4.5 kg

© 2019 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

Issue date 2019-01-31 Version: 9.0.1

EAN: 08 71010 37050 86

www.philips.com

