



Gaggia  
Super-automatic  
espresso machine

• Gaggia Unica

RI9933/70

## GAGGIA UNICA WILL SURPRISE YOU!

JUST PRESS A BUTTON TO HAVE A PERFECT ESPRESSO

easy and clean maintenance

### Features

- Adjustable dispensing head to fit every cup
- Durable ceramic grinder for pure coffee aroma
- Classic milk frother for a tasty Cappuccino
- Program the buttons with your favourite coffee drinks
- Easy cleaning thanks to removable brewing group
- Energy-saving Standby mode

**GAGGIA**  
MILANO

## HIGHLIGHTS

## SPECIFICATIONS

### Adjustable dispensing head



The dispensing head on your Gaggia machine is adjustable in height to accommodate different cup sizes.

### Personalise machine buttons



Programme the dispensing buttons on your electronic control panel to suit your own personal coffee taste.

### Durable ceramic grinder



Because a metal grinder might burn the coffee beans while grinding, all Gaggia's Espresso machines are equipped with an extremely durable ceramic grinder. A ceramic grinder will retain the purity of the coffee aroma while being equally as durable as a metal grinder. Additionally the coffee grind can be adjusted from coarse to fine, to match your preference.

### Removable brewing group



The removable brewing group in your full-automatic Espresso machine allows for easy cleaning and maintenance and can even be replaced separately if necessary. This saves money and increases the machine hygiene for a flawless coffee taste.

### Classic milk frother



The classic milk frother on this Gaggia Espresso machine, traditionally called a "Pannarello", turns milk into gorgeous milk froth within seconds for a Cappuccino, a Latte Macchiato and more. It also delivers hot water for tea.



Your coffee machine switches off automatically after one hour. In the energy-efficient standby mode your Gaggia machine will drain less than 1 kW/h and save you money compared to other espresso machines.

### Weight and dimensions

- Water tank capacity: 1.7 l
- Product weight: 9 kg
- Coffee bean capacity: 250 gr
- Waste container capacity: 14 servings
- Product dimensions: 32 x 37.2 x 46.1 cm

### Technical data

- Boiler: Stainless steel
- Frequency: 50 Hz
- Power: 1300 W
- Voltage: 230 V
- Pump Pressure: 15 Bar

### Features

- Brita Filter compatible
- Cup holder
- Hot water/Steam Nozzle
- Pannarello: Plastic
- Removable water tank

### Energy saving

- Energy saving: Automatic stand-by

### Design

- Colour: black/silver
- Materials and finishing: ABS

### Easy to use

- Usage: Adjustable coffee dispenser, Removable brewing group, Removable water tank

### Multi-Beverage

- Milk Variations: Pannarello: milk frothing