

# PHILIPS

Steam generator  
iron

PerfectCare  
Compact Plus

Max 6.5-bar pump pressure

Up to 430 g steam boost

1.5 l detachable water tank

Carry lock



GC7920/26



## Finish ironing 30 minutes faster

Compared to Philips steam iron Azur\*

So fast and convenient, and you'll never worry about burning clothes. Finish faster with twice as much steam as a steam iron. No settings to change and faster results with better wrinkle removal. Easy to iron your whole basket in one go.

### **OptimalTEMP technology, no settings required**

- Guaranteed no burns
- No temperature settings to change

### **Fast and powerful**

- Powerful steam for ultimate crease removal
- Smooth scratch-resistant SteamGlide soleplate for easy glide
- Calc-clean container included - no cartridges, no extra cost

### **Compact and convenient**

- Lightweight and compact for easy use and storage
- Large detachable water tank for easy refilling
- Safe and easy auto shut-off
- Carry lock for safe and easy transport

# Highlights

## Guaranteed no burns



Even if you're multi-tasking or get distracted, you'll never burn your clothes. Thanks to our OptimalTEMP technology, we promise this steam generator iron will never burn any ironable fabric. You can even leave it resting face down on your clothes or ironing board. No burns, no shine. Guaranteed.

## No settings to change



Save a step in your weekly ironing routine. You won't need to separate fabrics or change settings and wait for the temperature to change any more. Thanks to OptimalTEMP, you iron everything from your denim jeans to delicate silks without adjusting the temperature.

## Ultra-powerful steam



When you need to tackle tough creases with ease, rely on our continuous steam to do the hard work for you. Watch those creases melt away when you use an extra boost of steam

where you need it. And it's perfect when you want to steam vertical curtains or refresh hanging clothes.

## SteamGlide soleplate



Our special SteamGlide soleplate smoothly glides over any fabric. It's also non-stick, scratch-resistant and easy to clean.

## Easy descaling



It's easy to maintain your steam generator with Smart Calc Clean, our built-in descaling system. It will remind you when it's time to descale and includes a container to make descaling easy and safe. Since it is reusable you will save money and never need to buy extra cartridges.

## Compact and convenient



Thanks to its compact size it's light and easy to handle as you iron your clothes. It even fits on your ironing board. But don't think smaller means less powerful. Thanks to our exclusive

ProVelocity technology, we've made powerful steam generators that are lightweight and more compact than ever.

## 1.5 l detachable water tank



A 1.5 litre transparent tank gives you up to 1.5 hours of continuous use. See clearly how much water is left and refill easily at any time under the tap through the large filling door.

## Safe and easy auto shut-off



The automatic shut-off function automatically switches off your steam generator iron if it has not been used for a few minutes. This saves energy and gives you peace of mind.

## Safety carry lock



Lock your iron securely to the base station for easy carrying around the house and to reduce the risk of accidentally touching the hot soleplate.

# Specifications

## Technology

For all ironable fabrics  
No burns  
No temperature settings needed  
OptimalTEMP technology  
ProVelocity steam engine

## Fast crease removal

Continuous steam: Up to 120 g/min  
Power: 2400 W  
Pressure: Max 6.5-bar pump  
Ready to use: 2 min  
Steam boost: Up to 430 g  
Steam-on-demand  
Vertical steam  
Voltage: 220-240 V

## Easy to use

Auto shut-off  
Safe on all ironable fabrics: Even delicates like silk  
Soleplate gliding performance: 4 stars  
Soleplate scratch resistance: 4 stars

Soleplate name: SteamGlide  
Water tank capacity: 1500 ml  
Detachable water tank  
Hose length: 1.6 m  
Integrated power plug  
Power cord length: 1.65 m  
Ready to use: Light indicator, Sound indicator  
Refill anytime during use  
Tap water suitable  
Precision steam tip

## Scale management

Descaling and cleaning: Smart Calc Clean  
Descaling reminder: Light, Sound

## Storage

Carry lock: For transportation and safety  
Cord storage: Velcro fix  
Hose storage: Hose storage compartment

## Accessories included

Calc clean container

## Size and weight

Packaging dimensions (W x H x D): 23 x 26.5 x 42.6 cm  
Product dimensions (W x H x D): 20 x 23.3 x 37.1 cm  
Total weight with packaging: 3.85 kg  
Weight of iron: 1.3 kg  
Weight of iron + base: 2.8 kg

## Guarantee

2 year worldwide guarantee

## Green efficiency

Energy saving\*: 35 %  
Product packaging: 100% recyclable  
Recycled plastic used: 15 %  
User manual: 100% recycled paper

## Design

Colour: Aqua Blue

