



Saeco Xelsis
Super-automatic
espresso machine

- 15 Beverages
- Latteduo system
- Stainless Steel
- 12-step adjustable grinder



SM7685/04

The most advanced Saeco espresso machine yet

Up to 15 world's famous recipes from common Espresso & Cappuccino to specialty coffees like Flat White or Americano. Simply swipe the touch screen to select the drink and if desired customize it through our intuitive Coffee Equalizer™

Convenient Experience

- Featuring AquaClean for up to 5000* cups without descaling
- HygieSteam: automatic cleaning removes 99.99% milk residues
- Our largest sealed bean container to keep your beans fresh
- Removable brewing unit guarantees visual hygiene reassurance

High Quality Coffee

- 20,000 cups of finest coffee with durable ceramic grinders
- CSA badge: Saeco extracts the best part of your coffee beans
- Fast preparation with high-performance water boiler
- LattePerfetto for dense milk foam with fine texture


Personalized variety

- 8 profiles: Simply, store your personal taste preferences
- LatteDuo: Prepare and enjoy double serving of any recipe
- Our most advanced touch screen display with Coffee Equalizer
- Our largest bean container with aroma seal to keep your bean



PHILIPS

Saeco, a Philips brand



Highlights

100% Ceramic grinders



Our grinders are made of high-tech ceramic: exceptionally hard and precise. Fresh beans are gently ground, without risk of overheating: extracting all the best flavors and aroma, delivering a superior coffee taste for at least 20,000 cups.

8 User profiles



Everyone's personalized favorites can be saved in up to 8 user profiles using the convenient display

External Endorsement



Saeco technology allows you to extract the best flavors from your favorite coffee beans for

intense and authentic aroma and taste (roasted, chocolatey, nutty, fruity, flowery, spicy)

High-Performance boiler



Flawless coffee calls for perfect temperatures. Our high performance Thermoblock is made with light aluminum and a stainless steel body, which heats up to the optimal temperatures, fast

AquaClean Filter



AquaClean

AquaClean is our patented water filter, designed to improve the quality of your coffee by purifying water. It also prevents scale buildup in the water circuit of your coffee machine: make up to 5000* cups without descaling by replacing the filter regularly.

Automatic Cleaning Program



Our innovative automatic cleaning system HygieSteam removes 99.99% of milk residues with one touch

LatteDuo



Prepare and enjoy single or double serving of any coffee recipe with one touch, including Cappuccino or Latte Macchiato. All in one go.



IF Design Award

The iF DESIGN AWARD is among the most prestigious and largest design competitions in the world

Saeco won an iF Design award 2018: since 1953, a seal of excellence, a testimony of quality and a symbol of trust for users. This prestigious prize is awarded every year by iF International Forum Design GmbH in Hannover (Germany), the world's oldest independent design organization.

Specifications

Accessories

- Included: Measuring scoop, Water hardness test strip, Cleaning brush, Brew group grease, Milk container with metal lid, AquaClean filter

Finishing

- Material of main body: Stainless steel

General specifications

- Customizing per drink: Adjustable milk foam amount, Adjustable coffee strength, Adjustable cup volume, Adjustable temperature, User profiles, Adjustable milk/coffee order, Adjustable coffee taste
- Grinder settings: 12
- Number of user profiles: 8
- Type of boiler: Stainless steel boiler
- Type of carafe: Milk container metal lid
- Type of display: TFT
- Adjustable spout height: 75-148 mm
- Milk Solution: Latte Perfetto technology
- User Interface: Touch screen display
- Special functions: Ground coffee option

Service

- 1-year guarantee

Sustainability

- Energy label: B-Class*
- Power consumption stand-by: <0.5 W

Technical specifications

- Capacity milk carafe: 0.6 L

- Capacity waste container: 14 servings
- Capacity water tank: 1.7 L
- Coffee bean capacity: 450 g
- Filter compatibility: AquaClean
- Waste container: Frontal access
- Water tank: Frontal access
- Country of origin: Italy
- Drip tray capacity: 500 ml

Weight and dimensions

- Dimensions of product (WxDxH): 283x489x393 mm

Customization

- Aroma Strength Settings: 5
- Coffee and Milk Length: Adjustable
- Grinder Settings: 12
- Pre Brew Aroma control
- Temperature settings: 3
- User Profiles: 8

Other features

- Auto-Rinse & Guided descaling
- Main Switch ON / OFF button
- Quick Heat Boiler
- Removable brew group
- LED illuminated water tank
- LED in spout
- Warm milk function

Design

- Color: Stainless steel