# **PHILIPS**

### Handheld vacuum cleaner

### MiniVac

4.8V battery Bagless Cyclonic Crevice, brush tool, squeegee Wet & dry

### FC6142/01





## Powerful MiniVac for a better cleaning result Wet & Dry system and aerodynamic nozzle

Enjoy a better cleaning result with the powerful Philips MiniVac Wet&Dry 4.8 V vacuum cleaner. Clean both liquid spills and dry dirt in comfort with its wet-anddry system. The aerodynamic nozzle design ensures a superior dust pick-up.

#### High power guaranteed

Powerful 4.8 V NiMH batteries

#### Superior cleaning results

· Aerodynamic nozzle design for a better dust pick-up

#### **Optimal filtration**

· 2-stage bagless cyclonic airflow for optimal filtration

#### Easy to use

- Looped handle ensure optimum grip
- $\cdot$  One-step click-off nozzle for easy emptying

#### Always at hand

• Slim charging base (for wall or table)

# Highlights

#### Slim charging base (for wall or table)



You can store the Philips Mini Vac on a convenient charging base, mounted on a wall or placed on a table. This means the Mini Vac, with its powerful rechargeable battery, is always ready when you are.

#### 2-stage bagless cyclonic



The bagless cyclonic airflow keeps the dirt inside rotating to ensure optimal, high suction power and lasting cleaning performance. Its 2stage filtration system ensures that, once inside, the dirt cannot escape. The first filter blocks most dirt, while the second filter traps the finer dust particles.

#### Aerodynamic nozzle design

The aerodynamic nozzle design of the Philips MiniVac is created to ensure an optimum dust pick-up of even the most fine dust particles. The ergonomic shape of the nozzle helps you to clean even the most hard-to-reach areas.

#### Comfortable grip



The Philips Mini Vac has a looped handle that ensures optimum grip. You can grab the Mini Vac in any way you like.

#### Powerful 4.8 V NiMH batteries



Powerful 4.8 V NiMH batteries

#### One-step click-off nozzle

The Philips MiniVac vacuum cleaner is easy and quick to empty and hygienic to clean. The Philips MiniVac has a nozzle that easily clicks off in just one step, so you can empty the MiniVac without touching the dirt. FC6142/01

# Specifications

#### Design

Color: Blue Design features: Translucent dust chamber

#### Filtration

Dust capacity: 0.5 L Filter system: Wet and dry system

#### Nozzles and accessories

Accessories included: Charging base

#### Performance

Battery voltage: 4.8 V Charging time: 16-18 hour(s) Input power (max): 56 W Runtime: 9 minute(s) Suction power (max): 9 W Vacuum (max): 2.9 kPa Airflow (max): 530 l/s Sound power level: 76 dB

#### Weight and dimensions

Dimensions of packaging (LxWxH): 508 x 335 x 490 mm Weight of product: 1.4 kg Dimensions of product (LxWxH): 460 x 160 x 160 mm

© 2020 Koninklijke Philips N.V. All Rights reserved.

their respective owners.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or

Issue date 2020-05-07 Version: 14.12.1

12 NC: 8836 142 01010

www.philips.com

