

# PHILIPS

Food processor

Robust Collection

1200 W

4 L bowl



HR7781/00



## Culinary tools for life

### Easy clean processor for tough ingredients

Enjoy this powerful machine that can handle the most demanding ingredients with ingenious accessories. This Philips food processor HR7781/00 is part of the Robust Collection, a series of durable kitchen tools that make cooking a pleasure.

#### **Robustly built**

- Solid metal base
- Break-resistant 4 l bowl
- Power-efficient 1200 W motor
- 15-year guarantee on the motor

#### **The essentials - perfected**

- Innovative kneading hook for up to 2 kg heavy dough
- Innovative double-balloon beater for perfect whisking
- 3 metal discs to slice, grate and julienne
- Durable stainless-steel chopping knife
- Wide feeding tube takes large ingredients
- Bowl with drainage holes and dishwasher-safe accessories

#### **Technology - where it counts**

- Smooth, rimless surfaces for much easier cleaning

# Highlights

## 3 metal discs



It has 3 stainless steel metal discs: 1 for julienne or French fries, 1 for medium and small slicing and 1 for medium and small shredding.

## Durable chopping knife



The durable stainless-steel chopping knife chops your ingredients perfectly in seconds.

## Double-balloon beater



The double balloon beater can be used to whisk light to medium batter. With two balloons the result can be achieved more rapidly. Two beaters bring more air into egg whites or cream.

## Innovative kneading hook



The innovative kneading hooks process tough ingredients and can handle up to 2 kg of heavy dough. Due to its fast performance your dough is produced within minutes.

## Power-efficient 1200 W motor



The 1200 W motor of this Philips food processor handles more than 2 kg of bread or pizza dough.

## Easier to clean

This food processor is specially designed for easier cleaning. The smooth, rimless surfaces ensure food does not get stuck, making cleaning very easy.

## Solid metal base



The Food Processor is made of durable materials. It has a full metal housing body and it is equipped with accessories made of stainless steel and Zytel plastics to withstand high forces during application.

## Wide feeding tube



The wide feeding tube is designed to take large ingredients and whole fruits, so you don't need to pre-cut them any more.

## Extended product guarantee



15-year guarantee on the motor will be provided upon registration within 3 months after purchase.

# Specifications

## General specifications

2 speeds  
Non-slip feet  
Integrated cord storage  
Recipe booklet

## Accessories

**Balloon beater:** For whipping, whisking, mixing, battering and emulsifying  
**Kneading tool:** For kneading, heavy kneading and mixing dough  
**Stainless steel chopping knife:** chopping, cutting, crumbling, mashing, mincing  
**Julienne/French fry disk:** For julienne strips or French fries  
**Double-sided shredding disc:** For medium and small shredding  
**Double-sided slicing disc:** For medium and small slicing  
**Number of inserts/discs:** 3

## Design specifications

**Disks, chopping blade:** Stainless steel  
**Colour(s):** Aluminium and pumice grey

## Technical specifications

**Bowl capacity dry:** 4 l  
**Bowl volume capacity liquid:** 4 l  
**Bowl capacity dough:** 2000 g  
**Bowl capacity flour:** 1000 g  
**Speeds:** 2+ pulse  
**Frequency:** 50/60 Hz  
**Power:** 1200 W  
**Voltage:** 220-240 V  
**Safety:** Safety lock system for lid and bowl detection  
**Cord length:** 1.5 m  
**Higher speed:** 1500 RPM  
**Lower speed:** 600 RPM

## Dimensions

**Box dimension (W x H x D):** 47.5 x 39.0 x 42.6  
**Product weight:** 8.6 kg  
**Weight incl. Packaging:** 10.4 kg

## Easy to clean

Bowl with drainage holes  
Dishwasher-safe accessories  
Smooth and rimless surfaces

## Guarantee

**Extended Guarantee:** 5-year product guarantee and a 15-year guarantee on the motor

## Sustainability

**Made of recycled materials:** 25 %  
**Recyclable materials:** 89 %  
**Stand-by power consumption:** 0 W

