

PHILIPS

Saeco

Manual Espresso
machine

Poemia

Classic Milk Frother

Stainless steel



HD8327/47



Authentic Italian Espresso every day With pressurized crema filter

Saeco manual espresso machine offers enthusiasts of traditional preparation everything for a perfect daily espresso. The patented pressurized filter Crema guarantees a long lasting delicious crema, at every use.

Simplicity and speed of use

- Suitable for ground coffee and pads
- Delicious milk froth thanks to the classic milk frother
- Ergonomic in day by day operations

Every day use

- Stainless steel espresso machine
- Cup warmer

Highlights

Ground coffee and pads



For your convenience you can choose between ground coffee pads

Ergonomic in day by day



Refilling coffee powder or water, emptying the filter or the drip tray. All compartments are directly accessible for maximum convenience.

Full stainless steel



Premium material for long lasting machine and easy to clean.

Classic milk frother



This Saeco espresso machine comes with the classic milk frother that baristas call a “Pannarello”. It dispenses steam and is immersed in milk to prepare gorgeous milk foam. Unleash your inner barista by preparing your delicious milk specialties the traditional way!

Cup warmer



Pre-heat your cups letting the aroma unfold even better and guaranteeing a long-lasting crema.

Specifications

Sustainability

Power consumption brewing: 950 W

General specifications

Cups at the same time: 2

Suitable for: Ground coffee powder

Special functions: Manual milk frother Pannarello, Steam option, Hot water option

Ease of use and comfort: Cup warmer

Ease of cleaning & maintenance: Optional Brita water filter

Coffee drinks: Espresso

Finishing

Material boiler: Stainless steel (Inox)

Material drip tray: Stainless steel

Material filter holder: Stainless steel & plastic

Material of main body: Stainless steel

Material panarello: Stainless steel

Material water tank: Plastic

Country of origin

Made in: China

Design

Color: Stainless steel

Weight and dimensions

Weight of product: 4 kg

Dimensions of product (WxDxH): 200 x 265 x 297 mm

Service

1-year guarantee

Technical specifications

Pump pressure: 15 bar

Max. cup height: 75 mm

Water boilers: 1

Voltage: 120 V

Frequency: 60 Hz

Cord length: 0.8 m

Capacity water tank: 1.25 L

