



**Saeco GranAroma  
Deluxe  
Fully Automatic  
Espresso Machine**

- 18 coffee varieties
- 6 User profiles
- Glossy Black
- 5" Color touch TFT display

**SM6680**



# Your personal brew, tailored to you

## Easily personalize your coffee with taste presets

Intuitively personalize aromatic coffees like Cappuccino and Latte Macchiato with preset taste profiles via the CoffeeMaestro menu. Enjoy built-in Wi-Fi functions and enrich your coffee experience with software updates.


### **Smart connectivity**

- Create 18 coffee varieties at the touch of a button
- 3 taste presets tailored to your needs with CoffeeMaestro
- Advanced 5.4" color touchscreen display
- Connect your machine with built-in Wi-Fi
- Customize up to 6 coffee settings and add an ExtraShot
- Enjoy double servings of your favorite recipe with just one
- "Remove up to 99.9% of microorganisms on milk carafe parts\*\*"
- At least 20,000 cups with our most durable ceramic grinder
- Creates a dense milk foam with a fine texture
- Personalize up to 6 profiles and save your favorites
- Intuitive maintenance for consistent coffee quality
- Extends machine lifetime and improves coffee taste

 **Saeco**

**PHILIPS**

Saeco, a Philips brand



# Highlights

## 18 delicious coffee varieties

Explore a world of coffee to create at just the touch of a button, with 18 delicious varieties to choose from. From more familiar recipes such as Espresso and Cappuccino, to specialty coffees like Italian Espresso Macchiato.

## CoffeeMaestro

Effortlessly personalize your perfect cup with CoffeeMaestro. Simply select your desired taste profile from 3 pre-sets - Delicato, Intenso, Forte. The machine automatically adjusts the brewing settings like strength, coffee volume and pre-wetting time, to serve you just the right taste.

## 5" Color touchscreen display

Advanced 5.4" high-resolution color display features an intuitive touchscreen user interface, to master your coffee varieties with precise interaction.

## Built-in connectivity

The machine includes built-in Wi-Fi connectivity to ensure no part of the process is overlooked, with enhanced user features seamlessly controlled from the machine's display and to see availability of consumables at local retailers. Regular updates are based on software enhancements and machine learnings,

always striving to improve and enrich your experience and help you get the very best out of your machine.

## CoffeeEqualizer Touch

Create your own favorite recipe with CoffeeEqualizer Touch. Personalize your coffee to your precise taste preferences by customizing the strength, coffee and milk volume, temperature, amount of milk foam, and even the order of the coffee and milk. If desired, you can use the ExtraShot function to boost the coffee intensity.

## LatteDuo

Prepare and enjoy single or double servings of your favorite coffee recipe with just one touch, including Cappuccino and Latte Macchiato.

## HygieSteam

Our innovative automatic cleaning system, HygieSteam, removes 99.9% of microorganisms on milk carafe parts\*\*.

## 100% Ceramic Grinders

The best flavors and aromas are extracted from your beans with our most durable grinder. Made with 100% ceramic to be exceptionally hard and precise, and last for at least 20,000 cups of delicious, freshly ground

coffee. Easily adjust the grinder to your taste with 12-step levels.

## LattePerfetto

The external milk carafe with LattePerfetto technology creates a dense milk foam with a fine, silky texture, perfect for your favorite milk-based coffees.

## 6 User Profiles

Everyone's custom coffee favorites can be saved in up to 6 user profiles for instant selection on the high-resolution touch display. Easily personalize each profile down to the finest detail.

## Maintenance Dashboard

Keep an overview of the maintenance of your machine and receive status information e.g. on your water level or when you are running low on AquaClean.

## AquaClean Water Filter

AquaClean is our patented water filter, designed to improve the quality of your coffee with purified water and prevent scale build-up within the machine. Make up to 5000\* cups without descaling by replacing the filter regularly.

# Specifications

## Accessories

- Included: Measuring scoop, Water hardness strip test, Grease tube, Milk container, Milk Tube, AquaClean filter

## Country of origin

- Designed in: Italy
- Made in: Romania

## Finishing

- Material of main body: Plastic

## General specifications

- Milk Solution: External milk carafe
- Dishwasher safe parts: Drip tray & grid, Milk container & lid, HygieSteam container & holder, Coffee Grounds Container, Measuring scoop
- Customizing per drink: Aroma Strength

## Weight and dimensions

- Dimensions (WxDxH): 262 x 448 x 383 mm mm
- Weight: 8.5 - 9 kg

## Customization

- Aroma Strength Settings: 5
- Grinder Settings: 12
- Pre-brew Aroma control
- User Interface: Colored touch display TFT
- User Profiles: 6
- Temperature settings: 3
- Coffee and Milk Length: Adjustable

## Technical specifications

- Milk carafe capacity: 0.6 L
- Waste container capacity: 12 servings
- Water tank capacity: 1.8 L
- Type of boiler: Stainless steel boiler
- Type of carafe: Milk Container Plastic Lid

- Coffee bean capacity: 300 g
- Waste container: Frontal access
- Water tank: Frontal access
- Filter compatibility: AquaClean
- Drip tray capacity: 500 ml
- Frequency: 50 Hz
- Max. cup height: 150 mm
- Voltage: 230 V
- Color(s): Black
- Cord length: 1200 mm
- Pump pressure: 15 bar

## Variety

- Beverages: Americano, Café au Lait, Café Cortado, Caffé crema, Caffé Latte, Cappuccino, Coffee, Espresso, Espresso Lungo, Espresso Macchiato, Flat White, Hot water, Italian Cappuccino, Latte Macchiato, Melange, Milk froth, Ristretto, Travel Mug, Warm Milk
- Milk Double Cup

## Other features

- Removable brew group
- Aroma Seal
- LED in spout
- Auto-Rinse & Guided descaling
- Quick Heat Boiler

## Service

- 2-year worldwide guarantee

## Sustainability

- ECO setting
- Energy label: B-class
- Power consumption stand-by: <0.5 W
- Power consumption brewing: 1500 W
- Recyclable packaging material: > 95%