

# PHILIPS

Fully automatic  
espresso machines

Series 2200  
Connected

2 beverages

Classic Milk Frother

Matt black

Touch display

EP2520/10



## 2 delicious coffees from fresh beans, with ease Thanks to the intuitive touch display

Enjoy the delicious taste and aroma of coffee from fresh beans, at the perfect temperature, thanks to our intelligent brewing system. Link to Coffee+ App for extra functionalities and enjoy your coffee moment easier than ever.

### **A variety of coffees customized to your taste**

- Delicious milk froth thanks to the classic milk frother
- Easy selection of your coffee with intuitive touch display
- Adjust aroma strength and quantity via My Coffee Choice
- Easily adjust to your taste with 12-step grinder levels

### **High quality coffee from fresh beans**

- The perfect temperature, aroma and crema cup after cup\*
- 20,000 cups of finest coffee with durable ceramic grinders
- Aroma seal keeps your beans fresh for longer
- Easy button to buy your favorite Coffee Beans via Amazon

### **Effortless use and cleaning for everyday enjoyment**

- Up to 5000 cups\*\* without descaling thanks to AquaClean
- Easy cleaning thanks to fully removable brew group
- Easy access remote assistance & guidance via Coffee+ App
- Seamless remote control of your machine via Coffee+ App

# Highlights

## Classic milk frother



The Classic milk frother dispenses steam, allowing you to easily prepare silky smooth milk froth for your Cappuccino. Plus, with only two parts, the Classic Milk Frother is also easy to clean.

## Intuitive touch display



The irresistible taste and aroma of coffee from your fresh beans is just one touch away. Our intuitive touch display allows you to easily select your favorite coffee.

## My Coffee Choice



Adjust the strength and quantity of your beverage with the My Coffee Choice menu. Easily choose from three different settings to suit your preferences.

## 12-step grinder adjustment



Our durable ceramic grinders can be adjusted in 12 steps, so you can turn your beans into anything from ultra-fine powder to coarse grindings.

## Perfect temperature and aroma



The Aroma Extract system intelligently strikes the optimum balance between brewing temperature and aroma extraction by keeping the water temperature between 90 and 98°C, while regulating the water flow rate, so you can enjoy delicious coffees.

## 100% ceramic grinders



Our grinders are 100% pure ceramic and extremely hard and precise, so you can enjoy fresh aromatic coffee, for at least 20,000 cups.

## Preserve bean aroma



The new Aroma seal protects your favorite coffee beans and makes sure they preserve their original aroma over time, while reducing the grinder noise.

## AquaClean filter



The machine will prompt you to change the filter, after you will not need to descale your machine for up to 5000 cups\*\*, while enjoying clear and purified water. With Amazon Dash Replenishment (DRS), you can set up automatic delivery of AquaClean and Descalers, so you never run out.

## Removable brew group



The brew group is the heart of every fully automatic coffee machine, and should be cleaned regularly. The removable brew group allows you to clean it thoroughly just by rinsing it under the tap.

# Specifications

## Country of origin

Designed in: Italy

Made in: Romania

## General specifications

User Interface: Touch screen display

Milk Solution: Classic Milk Frother

Adjustable spout height: 85-145 mm

Dishwasher safe parts: Classic milk frother,  
Drip tray

Ease of cleaning & maintenance: AquaClean  
filter compatible

Coffee + App

## Technical specifications

Capacity waste container: 12 servings

Frequency: 50 Hz

Voltage: 230 V

Color & Finishing: Black, Matte Black

Cord length: 100 cm

Waste container: Frontal access

Water tank: Frontal access

Product dimensions: 246x371x433 mm

Weight of product: 7.5 kg

Coffee bean capacity: 275 g

Capacity water tank: 1.8 L

Filter compatibility: AquaClean

Pump pressure: 15 bar

## Customization

Aroma Strength Settings: 3

Grinder Settings: 12

Pre Brew Aroma control

Temperature settings: 3

## Variety

Beverages: Espresso, Coffee, Hot water

Coffee Powder Option

Double Cup

Milk Double Cup: No

## Other features

Removable brew group

Aroma Seal

Guided descaling

AquaClean

## Accessories

Included: Measuring scoop, Water hardness  
test strip, AquaClean filter, Grease tube

## Service

2-year guarantee

## Sustainability

ECO setting

Energy label: A-class

Power consumption brewing: 1500 W

Recyclable packaging material: > 95%

## Connectivity

Android compatibility: Phone and WiFi  
enabled Tablet from Android 8.0 onwards.

iOS compatibility: iPhone/iPad from iOS 12.0  
onwards.

WiFi Wireless Technology: 802.11 b/g/n (2.4  
GHz)

