

# PHILIPS

Fully automatic  
espresso machines

Series 3200

5 Beverages

LatteGo

White

Touch display

EP3243/50



## 5 delicious fresh bean coffees, easier than ever LatteGo, the fastest to clean milk system ever\*

Easily make aromatic coffee varieties like Espresso, Coffee, Cappuccino and Latte Macchiato at the touch of a button. LatteGo tops milk varieties with silky smooth froth, is easy to set up and can be cleaned in as little as 15 seconds\*

### A variety of coffees customized to your taste

- Enjoy 5 coffees at your fingertips, including cappuccino
- Silky smooth milk froth thanks to high speed LatteGo system
- Easy selection of your coffee with intuitive touch display
- Adjust aroma strength and quantity via My Coffee Choice
- Easily adjust to your taste with 12-step grinder levels

### High quality coffee from fresh beans

- The perfect temperature, aroma and crema cup after cup\*
- 20,000 cups of finest coffee with durable ceramic grinders
- Keep your beans fresh for longer thanks to the aroma seal

### Effortless use and cleaning for everyday enjoyment

- LatteGo is exceptionally easy to clean: 2 parts, no tubes
- Up to 5000 cups\* without descaling thanks to AquaClean
- Easy cleaning thanks to fully removable brew group
- Dishwasher safe parts for your convenience

# Highlights

## 5 aromatic coffees



Enjoy your favourite coffees for your special moments. Whether you crave for an espresso, a coffee or a milk based recipe, your fully-automatic espresso machine delivers a perfect in-cup result with no hassle and in no time!

## LatteGo milk system



Top your coffee off with a silky-smooth layer of milk froth. The LatteGo mixes milk and air at high speed in the round frothing chamber, then adds a splash-free, creamy layer of milk froth to your cup at just the right temperature.

## Intuitive touch display



The irresistible taste and aroma of coffee from fresh beans is just one touch away. Our intuitive touch display allows you to easily select your favorite coffee.

## My Coffee Choice



Adjust the strength and quantity of your beverage with the My Coffee Choice menu. Easily choose from three different settings to suit your preferences.

## 12-step grinder adjustment



Our durable ceramic grinders can be adjusted in 12 steps, so you can turn your beans into anything from ultra-fine powder to coarse grindings.

## Perfect temperature and aroma



The Aroma Extract system intelligently strikes the optimum balance between brewing temperature and aroma extraction by keeping the water temperature between 90 and 98°C, while regulating the water flow rate, so you can enjoy delicious coffees.

## 100% ceramic grinders



Our grinders are 100% pure ceramic: extremely hard and precise, so you can enjoy fresh aromatic coffee, for at least 20.000 cups.

## 2 parts, no tubes milk system



Our 2 parts milk system has no tubes or hidden parts and can be cleaned in as little as 15 seconds under tap\* or in the dishwasher.

## AquaClean filter



By changing the filter after being prompted by the machine, you will not need to descale your machine for up to 5000 cups\*, while enjoying clear and purified water.

# Specifications

## Country of origin

Designed in: Italy  
Made in: Romania

## General specifications

Ease of cleaning & maintenance: AquaClean filter compatible  
Adjustable spout height: 85-145 mm  
Milk Solution: LatteGo  
User Interface: Touch screen display  
Dishwasher safe parts: Drip tray, LatteGo

## Technical specifications

Capacity milk carafe: 0.26 L  
Capacity waste container: 12 servings  
Frequency: 50 Hz  
Voltage: 230 V  
Color & Finishing: Black, White  
Cord length: 100 cm  
Filter compatibility: AquaClean  
Waste container: Frontal access

Water tank: Frontal access

Weight of product: 8 kg  
Product dimensions: 246x371x433 mm  
Coffee bean capacity: 275 g  
Capacity water tank: 1.8 L  
Pump pressure: 15 bar

## Customization

Aroma Strength Settings: 3  
Grinder Settings: 12  
Pre Brew Aroma control  
Temperature settings: 3  
Coffee and Milk Length: Adjustable

## Variety

Beverages: Espresso, Hot water, Cappuccino, Coffee, Latte Macchiato, Americano  
Coffee Powder Option  
Double Cup  
Milk Double Cup: No

## Other features

Removable brew group  
Aroma Seal  
Guided descaling  
AquaClean

## Accessories

Included: AquaClean filter, Grease tube, Measuring scoop, Water hardness test strip, LatteGo storage lid

## Service

2-year guarantee

## Sustainability

ECO setting  
Energy label: A-class  
Power consumption brewing: 1500 W  
Recyclable packaging material: >95 %

