

PHILIPS

Fully automatic
espresso machines

Series 1200

2 beverages

Classic Milk Frother

Cashmere grey

Touch display

EP1224/03



2 delicious coffees from fresh beans, with ease

Thanks to the intuitive touch display

Enjoy the delicious taste and aroma of coffee from fresh beans, at the perfect temperature, thanks to our intelligent brewing system. The classic milk frother allows you to create a silky smooth cappuccino or latte macchiato with ease.

A variety of coffees customized to your taste

- Delicious milk froth thanks to the classic milk frother
- Adjust aroma strength and quantity via My Coffee Choice
- Easy selection of your coffee with intuitive touch display
- Easily adjust to your taste with 12-step grinder levels

High quality coffee from fresh beans

- 20,000 cups of finest coffee with durable ceramic grinders
- The perfect temperature, aroma and crema cup after cup*

Effortless use and cleaning for everyday enjoyment

- Easy cleaning thanks to fully removable brew group
- Up to 5000 cups* without descaling thanks to AquaClean
- Automatic descaling for your convenience
- Dishwasher safe parts for your convenience

Highlights

Classic milk frother

The Classic Milk Frother dispenses steam, allowing you to easily prepare silky smooth milk froth for your cappuccino. What's more? With only two parts, the Classic Milk Frother is also easy to clean.

Intuitive touch display

The irresistible taste and aroma of coffee from fresh beans is just one touch away. Our intuitive touch display allows you to easily select your favorite coffee.

My Coffee Choice

Adjust the strength and quantity of your beverage with the My Coffee Choice menu. Easily choose from three different settings to suit your preferences.

12-step grinder adjustment



Our durable ceramic grinders can be adjusted in 12 steps, so you can turn your beans into anything from ultra-fine powder to coarse grindings.

Perfect temperature and aroma



The Aroma Extract system intelligently strikes the optimum balance between brewing temperature and aroma extraction by keeping the water temperature between 90 and 98°C, while regulating the water flow rate, so you can enjoy delicious coffees.

100% ceramic grinders



Our grinders are 100% pure ceramic: extremely hard and precise, so you can enjoy fresh aromatic coffee, for at least 20.000 cups.

AquaClean filter



By changing the filter after being prompted by the machine, you will not need to descale your machine for up to 5000 cups*, while enjoying clear and purified water.

Removable brew group



The brew group is the heart of every fully automatic coffee machine, and should be cleaned regularly. The removable brew group allows you to clean it thoroughly just by rinsing it under the tap.

Automatic descaling alarm

It's easy to clean and maintain your coffee machine with the automatic program which notifies when you have to descale it. You can adjust the frequency of this procedure to match the water hardness at home.

Dishwasher safe parts



For your convenience, you can put the milk system, drip tray and the coffee ground container in the dishwasher. This will save time and ensure a hygienic cleaning.

Specifications

Accessories

Included: Measuring scoop, Water hardness test strip, Grease tube

Country of origin

Designed in: Italy
Made in: Romania

General specifications

Ease of cleaning & maintenance: AquaClean filter compatible

Adjustable spout height: 85 - 145 mm

Milk Solution: Classic Milk Frother

User Interface: Touch screen display

Dishwasher safe parts: Classic milk frother, Drip tray

Service

2-year guarantee

Sustainability

ECO setting

Energy label: A-class

Power consumption brewing: 1500 W

Recyclable packaging material: >95 %

Technical specifications

Capacity milk carafe: X L

Capacity waste container: 12 servings

Frequency: 60 Hz

Voltage: 230 V

Color & Finishing: Cashmere grey

Cord length: 100 cm

Filter compatibility: AquaClean

Waste container: Frontal access

Water tank: Frontal access

Weight of product: 7.5 kg

Product dimensions: 246x371x433 mm

Coffee bean capacity: 275 g

Capacity water tank: 1.8 L

Pump pressure: 15 bar

Customization

Grinder Settings: 12

Pre Brew Aroma control

Temperature settings: 3

Variety

Beverages: Espresso, Hot water, Coffee

Coffee Powder Option

Double Cup

Milk Double Cup: No

Other features

Removable brew group

Guided descaling

AquaClean

