

# PHILIPS

Fully automatic  
espresso machines

Philips 4300 Series

8 Beverages

LatteGo milk solution

Black

TFT display

EP4346/70



## 8 delicious fresh bean coffees, easier than ever LatteGo, the fastest to clean milk system ever\*

Easily make aromatic coffee varieties like Espresso, Coffee, Cappuccino and Latte Macchiato at the touch of a button. LatteGo tops milk varieties with silky smooth froth, is easy to set up and can be cleaned in as little as 15 seconds\*

### A variety of coffees customized to your taste

- Enjoy 8 coffees at your fingertips, including latte macchiato
- Silky smooth milk froth thanks to high speed LatteGo system
- Easy selection of your coffee with the intuitive display
- Adjust aroma and volume with the coffee customizer
- Your perfect cup, every time, thanks to 2 user profiles

### High quality coffee from fresh beans

- The perfect temperature, aroma and crema cup after cup\*
- Easily adjust to your taste with 12-step grinder levels
- 20,000 cups of finest coffee with durable ceramic grinders

### Effortless use and cleaning for everyday enjoyment

- Exceptionally easy to clean with LatteGo: 2 parts, no tubes
- Up to 5000 cups\* without descaling thanks to AquaClean
- Easy cleaning thanks to fully removable brew group
- Dishwasher safe parts for your convenience

# Highlights

## 8 delicious coffees



Every moment has its own kind of coffee to enjoy. From powerful espresso to indulgent cappuccino, your fully automatic espresso machine delivers a perfect in-cup result without any fuss in no time.

## LatteGo milk system



Top your coffee off with a silky-smooth layer of milk froth. The LatteGo mixes milk and air at high speed in the round frothing chamber, then adds a splash-free, creamy layer of milk froth to your cup at just the right temperature.

## Intuitive display



There's little standing between you and your next delicious cup of coffee with our easy to use display. In a few steps you can customize your fresh-bean flavor and flow smoothly from craving to cup.

## Coffee customizer



Make any coffee your own with the coffee customizer's easily adjustable settings for intensity, coffee and milk length.

## User profiles

Enjoy coffee you love the same way every time with two user profiles that store your customized recipes. With an extra guest profile, your visitors can savor a coffee exactly the way they like, without changing yours.

## Perfect temperature and aroma



The Aroma Extract system intelligently strikes the optimum balance between brewing temperature and aroma extraction by keeping the water temperature between 90 and 98°C, while regulating the water flow rate, so you can enjoy delicious coffees.

## 12-step grinder adjustment



Our durable ceramic grinders can be adjusted in 12 steps, so you can turn your beans into anything from ultra-fine powder to coarse grindings.

## 100% ceramic grinders



Our grinders are 100% pure ceramic: extremely hard and precise, so you can enjoy fresh aromatic coffee, for at least 20.000 cups.

## Exceptionally easy to clean



For your convenience, you can put LatteGo drip tray and the coffee ground container in the dishwasher. This will save time and ensure a hygienic cleaning.

## AquaClean filter



By changing the filter after being prompted by the machine, you will not need to descale your machine for up to 5000 cups\*, while enjoying clear and purified water.

# Specifications

## Country of origin

Designed in: Italy  
Made in: Romania

## General specifications

Ease of cleaning & maintenance: AquaClean filter compatible  
Type of display: TFT  
Adjustable spout height: 85 - 145 mm  
Milk Solution: LatteGo  
Dishwasher safe parts: LatteGo, Drip tray

## Technical specifications

Capacity milk carafe: 0.26 L  
Capacity waste container: 12 servings  
Frequency: 50 Hz  
Max. cup height: 150 mm  
Voltage: 230 V  
Color(s): Black  
Finishing: Spraypainted Silver specchiato  
Cord length: 100 cm  
Filter compatibility: AquaClean  
Waste container: Frontal access

Water tank: Frontal access

Weight of product: 8 kg  
Product dimensions: 246x372x433 mm  
Coffee bean capacity: 275 g  
Capacity water tank: 1.8 L  
Pump pressure: 15 bar

## Customization

Aroma Strength Settings: 5  
Grinder Settings: 12  
Pre Brew Aroma control  
User Profiles: 2, Guest  
Temperature settings: 3  
Coffee and Milk Length: Adjustable

## Variety

Beverages: Espresso, Hot water, Cappuccino, Coffee, Milk froth, Ristretto, Latte Macchiato, Café au Lait, Americano, Caffé crema  
Coffee Powder Option  
Double Cup  
Milk Double Cup: No

## Other features

Removable brew group  
Aroma Seal  
Guided descaling  
AquaClean

## Accessories

Included: Measuring scoop, Water hardness test strip, AquaClean filter, Grease tube, LatteGo storage lid

## Sustainability

ECO setting  
Power consumption brewing: 1500 W  
Recyclable packaging material: > 95%

## Bazaarvoice\_DA\_CO\_FAM

S4300: PHI 4300 LatteGo

## Service

2-year guarantee

