

PHILIPS

Fully automatic
espresso machines

Series 2200

3 Beverages

LatteGo

Matte black

Touch display

EP2230/10



3 delicious fresh bean coffees, easier than ever LatteGo, the fastest to clean milk system ever*

Easily make aromatic coffee varieties like Espresso, Coffee and Cappuccino at the touch of a button. LatteGo tops milk varieties with silky smooth froth, is easy to set up and can be cleaned in as little as 15 seconds*

A variety of coffees customized to your taste

- Silky smooth milk froth thanks to high speed LatteGo system
- Adjust aroma strength and quantity via My Coffee Choice
- Easy selection of your coffee with intuitive touch display
- Easily adjust to your taste with 12-step grinder levels
- Enjoy 3 coffees at your fingertips

High quality coffee from fresh beans

- Keep your beans fresh for longer thanks to the aroma seal
- 20,000 cups of finest coffee with durable ceramic grinders
- The perfect temperature, aroma and crema cup after cup*

Effortless use and cleaning for everyday enjoyment

- Easy cleaning thanks to fully removable brew group
- Up to 5000 cups* without descaling thanks to AquaClean
- LatteGo is exceptionally easy to clean: 2 parts, no tubes
- Dishwasher safe parts for your convenience

Highlights

LatteGo milk system



Top your coffee off with a silky-smooth layer of milk froth. The LatteGo mixes milk and air at high speed in the round frothing chamber, then adds a splash-free, creamy layer of milk froth to your cup at just the right temperature.

Intuitive touch display



The irresistible taste and aroma of coffee from fresh beans is just one touch away. Our intuitive touch display allows you to easily select your favorite coffee.

Perfect temperature and aroma



The Aroma Extract system intelligently strikes the optimum balance between brewing temperature and aroma extraction by keeping the water temperature between 90 and 98°C, while regulating the water flow rate, so you can enjoy delicious coffees.

My Coffee Choice



Adjust the strength and quantity of your beverage with the My Coffee Choice menu. Easily choose from three different settings to suit your preferences.

3 aromatic coffees



Enjoy your favourite coffees for your special moments. Whether you crave for an espresso, a coffee or a milk based recipe, your fully-automatic espresso machine delivers a perfect in-cup result with no hassle and in no time!

12-step grinder adjustment



Our durable ceramic grinders can be adjusted in 12 steps, so you can turn your beans into anything from ultra-fine powder to coarse grindings.

100% ceramic grinders



Our grinders are 100% pure ceramic: extremely hard and precise, so you can enjoy fresh aromatic coffee, for at least 20.000 cups.

2 parts, no tubes milk system



Our 2 parts milk system has no tubes or hidden parts and can be cleaned in as little as 15 seconds under tap* or in the dishwasher.

AquaClean filter



By changing the filter after being prompted by the machine, you will not need to descale your machine for up to 5000 cups*, while enjoying clear and purified water.

Specifications

Accessories

Included: Measuring scoop, Water hardness test strip, AquaClean filter, Grease tube, LatteGo storage lid

Country of origin

Designed in: Italy

Made in: Romania

General specifications

Ease of cleaning & maintenance: AquaClean filter compatible

Adjustable spout height: 85–145 mm

Milk Solution: LatteGo

User Interface: Touch screen display

Dishwasher safe parts: Drip tray, LatteGo

Service

2-year guarantee

Sustainability

ECO setting

Energy label: A-class

Power consumption brewing: 1500 W

Recycled materials: >95 %

Technical specifications

Capacity milk carafe: 0.26 L

Capacity waste container: 12 servings

Frequency: 50 Hz

Voltage: 230 V

Color & Finishing: Black, Matte Black

Cord length: 100 cm

Filter compatibility: AquaClean

Waste container: Frontal access

Water tank: Frontal access

Weight of product: 8 kg

Product dimensions: 246x371x433 mm

Coffee bean capacity: 275 g

Capacity water tank: 1.8 L

Pump pressure: 15 bar

Customization

Aroma Strength Settings: 3

Grinder Settings: 12

Pre Brew Aroma control

Temperature settings: 3

Coffee and Milk Length: Adjustable

Variety

Beverages: Espresso, Hot water, Cappuccino, Coffee

Coffee Powder Option

Double Cup

Milk Double Cup: No

Other features

Removable brew group

Aroma Seal

Guided descaling

AquaClean

