

PHILIPS

Fully automatic
espresso machines

Philips 4300 Series

8 Beverages

LatteGo milk solution

Black

TFT display

EP4347



8 delicious fresh bean coffees, easier than ever LatteGo, the fastest to clean milk system ever*

Easily make aromatic coffee varieties like Espresso, Coffee, Cappuccino and Latte Macchiato at the touch of a button. LatteGo tops milk varieties with silky smooth froth, is easy to set up and can be cleaned in as little as 15 seconds*

A variety of coffees customized to your taste

- Adjust aroma and volume with the coffee customizer
- Silky smooth milk froth thanks to high speed LatteGo system
- Your perfect cup, every time, thanks to 2 user profiles
- Easy selection of your coffee with the intuitive display
- Enjoy 8 coffees at your fingertips, including latte macchiato

High quality coffee from fresh beans

- 20,000 cups of finest coffee with durable ceramic grinders
- The perfect temperature, aroma and crema cup after cup*
- Easily adjust to your taste with 12-step grinder levels

Effortless use and cleaning for everyday enjoyment

- Easy cleaning thanks to fully removable brew group
- Up to 5000 cups* without descaling thanks to AquaClean
- Dishwasher safe parts for your convenience
- Exceptionally easy to clean with LatteGo: 2 parts, no tubes

Highlights

100% ceramic grinders



Our grinders are 100% pure ceramic: extremely hard and precise, so you can enjoy fresh aromatic coffee, for at least 20.000 cups.

AquaClean filter



By changing the filter after being prompted by the machine, you will not need to descale your machine for up to 5000 cups*, while enjoying clear and purified water.

Removable brew group



The brew group is the heart of every fully automatic coffee machine, and should be cleaned regularly. The removable brew group allows you to clean it thoroughly just by rinsing it under the tap.

Perfect temperature and aroma



The Aroma Extract system intelligently strikes the optimum balance between brewing temperature and aroma extraction by keeping the water temperature between 90 and 98°C, while regulating the water flow rate, so you can enjoy delicious coffees.

12-step grinder adjustment



Our durable ceramic grinders can be adjusted in 12 steps, so you can turn your beans into anything from ultra-fine powder to coarse grindings.

Dishwasher safe parts



For your convenience, you can put the milk system, drip tray and the coffee ground container in the dishwasher. This will save time and ensure a hygienic cleaning.

LatteGo milk system



Top your coffee off with a silky-smooth layer of milk froth. The LatteGo mixes milk and air at high speed in the round frothing chamber, then adds a splash-free, creamy layer of milk froth to your cup at just the right temperature.

User profiles

Enjoy coffee you love the same way every time with two user profiles that store your customized recipes. With an extra guest profile, your visitors can savor a coffee exactly the way they like, without changing yours.

Intuitive display



There's little standing between you and your next delicious cup of coffee with our easy to use display. In a few steps you can customize your fresh-bean flavor and flow smoothly from craving to cup.

8 delicious coffees



Every moment has its own kind of coffee to enjoy. From powerful espresso to indulgent cappuccino, your fully automatic espresso machine delivers a perfect in-cup result without any fuss in no time.

Specifications

Accessories

Included: Measuring scoop, Water hardness test strip, AquaClean filter, Grease tube, LatteGo storage lid

Country of origin

Designed in: Italy

Made in: Romania

General specifications

Ease of cleaning & maintenance: AquaClean filter compatible

Type of display: TFT

Adjustable spout height: 85 - 145 mm

Milk Solution: LatteGo

Dishwasher safe parts: Drip tray, LatteGo

Sustainability

ECO setting

Power consumption brewing: 1500 W

Recyclable packaging material: > 95%

Technical specifications

Capacity milk carafe: 0.26 L

Capacity waste container: 12 servings

Frequency: 50 Hz

Max. cup height: 150 mm

Voltage: 230 V

Color(s): Black

Finishing: Spraypainted Silver specchiato

Cord length: 100 cm

Filter compatibility: AquaClean

Waste container: Frontal access

Water tank: Frontal access

Weight of product: 8 kg

Product dimensions: 246x372x433 mm

Coffee bean capacity: 275 g

Capacity water tank: 1.8 L

Pump pressure: 15 bar

Customization

Aroma Strength Settings: 5

Grinder Settings: 12

Pre Brew Aroma control

User Profiles: 2, Guest

Temperature settings: 3

Coffee and Milk Length: Adjustable

Variety

Beverages: Espresso, Coffee, Americano, Cappuccino, Latte Macchiato, Café au Lait, Caffé crema, Ristretto, Milk froth, Hot water

Coffee Powder Option

Double Cup

Milk Double Cup: No

Other features

Removable brew group

Aroma Seal

Guided descaling

AquaClean

Service

2-year guarantee

