

PHILIPS

AVENT



Fast bottle warmer

Warms evenly, no hotspots

Warms quickly

Gentle defrosting

Warms baby food too



SCF355/00

Our fastest electric bottle warmer

Quickly and evenly warms your milk

For days when you're rushed off your feet, this Philips Avent baby bottle warmer warms your milk quickly and evenly in just 3 minutes. Easy to operate, it features a handy defrost setting and can also be used to warm baby food.

Easy to use

- Easy to operate with helpful warming guide
- Keep your milk warm

Convenient and compatible

- Gentle defrost setting for baby bottles
- Compatible with Philips Avent bottles and containers
- Use to warm baby food too

Even warming

- Warms quickly and evenly

Fast warming

- Warms baby bottles in 3 minutes

Highlights

Warms in 3 minutes



The bottle warmer will warm 150 ml/5 oz of milk in just 3 minutes*.

Warms quickly and evenly



The bottle warmer warms quickly and evenly. By circulating the milk continuously as it warms, hot spots are also prevented.

Gentle defrost setting



The bottle warmer features a handy defrost setting. Safer than defrosting in a microwave and more convenient than using water. Simply select the setting to defrost frozen milk or baby food to liquid.

Warms baby food too



As well as baby bottles, you can also use the bottle warmer to gently and evenly warm baby food.

Fully compatible

The bottle warmer is fully compatible with all Philips Avent bottles and containers*. Use it to warm bottles and baby food containers conveniently.

Easy to operate

Warming reference table			
		Start temperature of milk	
Milk content	20°C	5°C	Frozen
60-90ml/2-3oz	3 min	4.5 min	1-1.5 hrs
90-110ml/3-4oz	3 min	5.5 min	
125-150ml/4-5oz	3 min	3.5 min	
180-210ml/6-7oz	4 min	5.5 min	1.5-2.5 hrs
240-260ml/8-9oz	4.5 min	7 min	
290-330ml/10-11oz	5 min	7.5 min	

Simply turn the knob to switch the baby bottle warmer on and select your warming setting. The bottle warmer comes with a helpful warming reference table so you can easily work out how long the warming will take.

Keep your milk warm



Milk or baby food is warmed at a slow pace, it will be kept warm at the right temperature and be ready when you need it.

Specifications

Product Material

ABS
PP

Technical specifications

Power consumption: 300 W
Voltage: 220-240 V, 50/60 Hz
Safety Classification: Class 1

Consumer Trade Item

Height: 18.5 cm
Width: 17.5 cm
Length: 16 cm
Net weight: 0.565 kg
Gross weight: 0.773 kg
GTIN: 8710103658443
Country of origin: CN
Harmonized system code: 85167970

Outer Carton

Height: 37.8 cm
Width: 16.8 cm
Length: 36 cm
Net weight: 2.26 kg
Gross weight: 3.484 kg
GTIN: 18710103658440

Pallet

Height: 195 cm
Width: 72 cm
Length: 117.6 cm
Net weight: 158.2 kg
Gross weight: 247.456 kg
GTIN: 68710103658445

Weight and dimensions

Product dimensions (W x H x D): 160.4 x 139.9 x 148.55 mm
Retail pack dimensions (WxHxD): 175 x 185 x 160 mm

Country of origin

Designed in: Europe
Produced in: China

What is included

Bottle warmer: 1 pcs

Pallet Layer

Height: 37.8 cm
Width: 72 cm
Length: 117.6 cm

Development stages

Stage: All



* In the case =< 150 ml/5 oz of milk at a temperature of 20°C/70°F in a Philips Avent Classic / Natural bottle of 260 ml/9 oz.
* Philips Avent breast milk bags and 2 oz/60 ml bottles cannot be used in this bottle warmer.