



Philips Viva Collection  
Kettle

**1.7 L, 1800 W**

Double housing  
Keep warm  
Spring lid

**HD9316/03**

## Safe and easy boiling

Stainless steel kettle with keep-warm function

The body of the new Philips electric kettle uses food-grade standard stainless steel, keep-warm heating with no reboiling, providing rapid water boiling with peace of mind!

### Easy to use

- Stylish upright body with brushed stainless steel finish
- Cord winder for easy storage
- 360° cordless pirouette base, for easier handling
- Detachable stainless steel filter for easy cleaning
- Easy opening and filling
- One-touch spring lid helps to avoid scalding

### Safe to use

- Strix controller
- Steam sensor, dry boiling and overheating prevention
- PTC technology for keep-warm heating with no reboiling
- Food grade stainless steel metal (SUS304)

# PHILIPS

# Highlights

## PTC Technology



Water temperature maintained at  $85\pm5^\circ\text{C}$  with no reboiling. Simple operation with keep-warm switch and indicator

## Triple protection

Steam sensor, dry boiling and overheating prevention

## Easy opening and filling



Easy opening and filling

## Cord winder



Power cable length adjustable as required for easy storage

## Stylish upright body



Breaks from the rounded shape of traditional kettles, stylish upright body with brushed stainless steel finish

## Detachable filter

Detachable stainless steel filter effectively filters every cup of water. Detachable design allows for convenient cleaning

## Food grade metal parts



Food grade stainless metal parts (SUS304) to guarantee a safe and clean cup of water.

## Strix controller



UK-designed Strix controller provides multi safety system against boil-dry, with auto switch off when ready or when lifted from the base.

## One-touch spring lid



Easy opening and closing helps to avoid scalding

## 360° cordless pirouette base

Easier handling

# Specifications

## Design specifications

- Color(s): Metallic silver
- Materials of main body: Stainless steel

## Dimensions and weight

- Product dimensions (L×W×H):  
23.2×15.3×24.8 cm
- Packaging dimensions (L×W×H):

18.0×18.0×26.2 cm

- Product weight: 1.0 kg

## Technical specifications

- Capacity: 1.7 L
- Cord length: 0.75 m
- Rated frequency: 50 Hz
- Rated input power: 1800 W
- Rated voltage: 220 V



Issue date 2023-10-25

Version: 7.7.1

EAN: 87 10103 63086 9

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)