



Philips PerfectCare 7000
Series
Steam Generator

Guaranteed no burns*
1.8 L detachable water tank
Ultra-light iron



PSG7030/20

Incredibly light and powerful

Effortless ironing. Great results.

PerfectCare 7000 series is designed for your comfort and convenience. Ultra-light and easy to handle, with powerful steam to achieve great results fast. With OptimalTEMP technology to guarantee no burns on all ironable garments.

Powerful performance

- Lightweight iron ideal for vertical steaming

Powerful performance

- SteamGlide Elite soleplate for ultimate gliding performance

Extra convenient to use

- Automatic shut-off when iron is left unattended

Powerful performance

- Powerful steam for crease removal

Extra convenient to use

- 1.8 L detachable water tank for easy refilling

PHILIPS

Highlights

OptimalTEMP



With OptimalTEMP technology you achieve great results with one ideal temperature setting. We guarantee that this iron will never cause burns to any ironable fabric when it is left unattended. You can safely leave it resting on your clothes or ironing board.

Powerful steam



Strong, continuous steam for effective crease removal of even the most stubborn creases on the thickest fabrics.

No temperature setting needed



Iron everything from silk to jeans without adjusting the temperature and no burns guaranteed. Thanks to OptimalTEMP, no dial or settings are needed. So there's no more pre-sorting the laundry or waiting for the iron to heat up and cool down. You're ready for any fabric, anytime.

Lightweight iron



The iron is amazingly light and comfortable to handle, gliding easily and reducing wrist strain. Its minimal weight of only 800 g also makes it easy for vertical steaming of curtains and hanging clothes.

1.8 l detachable water tank



The 1.8-litre transparent water tank gives you up to 2 hours of continuous use. When the water tank is empty, you will be reminded by the indicator light to refill at any time, which you can easily do under the tap through the large filling door.

SteamGlide Elite soleplate



SteamGlide Elite is our best soleplate for ultimate gliding performance and maximum scratch resistance. Its stainless steel base is twice as hard as a regular aluminium base, and

our patented 6-layer coating with advanced titanium layer glides effortlessly for the fastest results.

Easy De-calc



Regular descaling protects your iron, extends its lifetime and ensures the best steam performance. Our exclusive Easy De-Calc system collects limescale continuously with an indicator light to tell you when it needs emptying. Simply remove the plug and let the water and scale particles flow out.

Auto-shut off



Auto-shut off to save energy and for peace of mind.

Safety carry lock



Lock your iron securely to the base station for easy carrying around the house and to reduce the risk of accidentally touching the hot soleplate.

Specifications

Easy to use

- Water tank capacity: 1800 ml
- Safe on all ironable fabrics
- Heat-up time: 2 min
- Soleplate: SteamGlide Elite
- Detachable water tank
- Low water alert
- Refill anytime during use
- Tap water suitable

Technology

- OptimalTEMP technology

General specifications

- Hose length: 1.7 m
- Hose storage: Compartment
- Power cord length: 1.65 m
- Power cord storage: Velcro fix
- Warranty: 2 year worldwide guarantee
- Energy saving: 20%

Fast crease removal

- Continuous steam rate: Up to 120 g/min
- Pressure: Max 8.0 bar
- Power: Max 2100 W
- Steam boost: Up to 600 g
- Voltage: 220 - 240 V

Scale management

- Descaling and cleaning: Easy De-calc Plus
- Calc clean reminder: Light

Size and weight

- Packaging dimensions (W x H x D): 31.5 x 31.5 x 47.5 cm
- Weight of iron: 0.8 kg
- Product dimensions (W x H x D): 24 x 27.5 x 42 cm
- Total weight with packaging: 5.3 kg
- Weight of iron + base: 3.85 kg



Issue date 2021-10-15

Version: 4.4.1

EAN: 08 72038 90011 92

© 2021 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* On all ironable fabrics