

600W



Philips Viva Collection
Juicer

3 step easy juicing
Turbo torque motor

HL7577/00

More juice, less hassle

Continuous juicing of 1000kgs of fruits*

Juicing made easy in three steps! New Philips juicer removes the hassle of multiple locking and other attachments. The juicer is powered with 600W turbo power motor which supports juicing of even tough fruits and vegetables.

Turbo torque motor for maximum juice extraction

- Higher torque density motor support efficient juicing
- Powerful 600W motor tested for high endurance
- continuous juicing of even tough ingredients
- Speed settings for efficient juicing performance

Nutri- juicer jar for easy juicing

- 3 step integrated design facilitates easy fitment
- Drip-free spout
- Easy to lock and unlock jars
- Rust free blades

Quick Clean

- Dish wash safe accessories
- Fewer parts and attachments for easy cleaning
- Less groove design for easy cleaning and maintenance

PHILIPS

Highlights

Higher torque density motor



Turbo power motor supports maximum extraction of juice from even tough ingredients. This powerful motor supports continuous juicing of hard fruits and vegetables up to 1000Kgs* under conditions 1 minute juicing and 2 minutes cleaning time. Additionally, the motor is tested for 5 years life and gives advantage of locked rotor motor wattage up to 1600W.

Powerful 600W motor tested



Turbo power motor supports maximum extraction of juice from even tough ingredients. This powerful motor supports continuous juicing of hard fruits and vegetables up to 1000Kgs* under conditions 1 minute juicing and 2 minutes cleaning time. Additionally, the motor is tested for 5 years life and gives advantage of locked rotor motor wattage up to 1600W

Speed settings

Speed settings for efficient juicing performance

continuous juicing

continuous juicing of even tough ingredients

Nutri-Juicer Jar



3 easy steps for easy juicing 1) Place the Nutri-Juicer jar on the base unit and rotate clockwise to lock 2) Press the cutter sieve on the coupler and push down firmly 3) Place the Nutri-Juicer lid, rotate clockwise to lock and start juicing

Drip-free spout



Nutri-juicer jar comes with round chute for easy feeding of fruits and vegetables and drip-free stop spout giving hassle free juicing experience.

Rust free blades

Rust free blades

Easy to lock and unlock jars



Easy to lock and unlock jars

easy cleaning and maintenance



Less groove design for easy cleaning and maintenance

Quick Clean



Fewer parts and attachments makes juicing experience a delight. Most of the parts of juicer have less grooves and sharp edges so that it is easy to clean and maintain.

Dish wash safe accessories

Dish wash safe accessories

Specifications

Weight and dimensions

- Dimensions of packaging (LxWxH): 315x315x385 mm
- Weight incl. packaging: 3.9 kg
- Feeding tube diameter: 58 mm

Country of origin

- Made in: India

Technical specifications

- Cord length: 1.2 m
- Power: 600 W
- Voltage: 230 V
- Frequency: 50 Hz
- RPM blender (max): 20000 r/min

General specifications

- Non-slip feet
- Number of speed settings: pulse + 3 speed
- Pulse
- Overload protection
- Juicer locking Mechanism: Rotation lock

Accessories included

- Detachable Spout
- Pusher

Design specifications

- Material seive: Plastic + Metal
- Color(s): White and Pearl Blue

Weight and dimensions

- Dimensions of product (LxWxH): 272x229x338 mm
- Weight of product: 2.8 kg

Sustainability

- Packaging: <gt;> 90% recycled materials
- User manual: 100% recycled paper

Service

- 2-year product Warranty
- Other Warranty: 5 Year motor warranty



Issue date 2022-06-21

Version: 3.3.1

EAN: 08 71010 39052 33

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* 1 min juicing time and 2 min cleaning time, validated by external lab