

PHILIPS

Wake-up Light

Wake up with light

1 natural sound & 1 yoga sound

FM radio & Bedside lamp

Sunset Simulation

HF3507/10



Wake up with light, feeling more refreshed with a Wake-up Light that wakes you up naturally

Inspired by nature's sunrise the Philips Wake-up Light uses a unique combination of light and sound to wake you in a more natural way. It helps you to feel more refreshed, so that it is easier get out of bed.

Natural light wakes you gradually

- Sunrise Simulation wakes you gradually
- Bedside light with 10 light settings
- Choice of 2 different wake up sounds
- Dimming light gently sends you off to sleep

Naturally designed around you

- 4 display brightness levels - adjust to your preference
- Snooze function
- FM radio lets you wake up with your favorite radio show

Naturally proven to work

- Developed by Philips, experts in light for over 100 years.
- The only Wake-up Light clinically proven to work
- Time back-up (4-8h)

Highlights

Bedside Light



The sensitivity to light differs per person. In general, when using a higher light intensity a person needs less time to become fully awake. The 10 light intensities of the Wake-up light can be personalized and even be set up to 200 lux.

Developed by Philips



Philips was founded over a 100 years ago as a company that produced and sold lightbulbs. Over 100 years Philips grew into a global company that brings innovation in lots of different areas. To this day lighting still is the soul of Philips. The Wake-up Light is proud to continue its heritage by building on years of knowledge and expertise of the world's most well know lighting expert.

Proven by scientists



At this moment in time the Philips wake-up light is the only one scientifically proven to work. In order to make the Wake-up Light the best possible product it can be in genuinely waking you up naturally and energized we have done a lot of clinical research. This research was conducted by independent

science facilities to study and prove the effects of the wake-up light on the overall wake up experience. This way we have proven, among other things, that the Philips Wake-up Light not only wakes you more naturally, but also more energized and that it improves your mood in the morning.

Snooze function



The sound stops when you tap the top of the product. After 9 minutes the sound will gently start playing again.

Sunrise Simulation



Inspired by nature's sunrise, light gradually increases within 30 minutes until your room is filled with bright yellow light. This process of changing an increasing light stimulates your body to wake up naturally. By the time light has filled the room your chosen natural sound completes the wake up experience, leaving you ready for the day ahead.

4 display brightness levels



The brightness of the display can change from high-medium-low-very low-none.

1 natural sound & 1 yoga sound



At your set wake up time a sound will play to complete the wake up experience and ensure you are awake. The selected sound gradually increases in volume to your selected level within one and a half minute. You can choose from one natural bird sound and one yoga sound.

FM Radio



Listen to your favorite radio show while you are waking up.

Sunset Simulation



Sunset simulation is a light therapy used before you go to sleep. Sunset simulation prepares your body to fall asleep by gradually decreasing light to your set duration.

Specifications

Easy to use

Anti-slip rubber feet
Snooze type: Tap top to snooze
Display brightness control: 4 settings
Instore demo function
Number of alarm times: 1
Charges iPhone/ iPod Touch: No
Snooze Duration: 9 minute(s)
Controlled by iPhone App: No

Logistic data

Country of origin: China
CTV Code EUR: 884350650

Sound

Number of Wake-up Sounds: 2
Music from smartphone / iPod: No
FM Radio

Well-being by light

Drift to sleep naturally
Increase energy in morning
Wake up gradually by light

Natural light

Brightness settings: 10
Light intensity: 200 lux
Sunrise simulating process: 30 minutes
Colors in sunrise simulation: Bright Yellow
Fall Asleep function

Technical

Box Dimensions (WxHxD): H200 x W200 x D130 mm
Box Weight: 600 gram
Cord Length EU/US: 150/180 CM
Frequency: 50/60 Hz
Insulation Device: Class III

Insulation Power Plug: Class II (double isolation)

Power Input: 7.5 W
Power Output Adapter: 5.4 W
Product Dimensions: H 180mm x W 180mm x D 115mm
Product Weight: 290 gram
Replaceable Lamp: No
Type of Lamp: Liteon SMD Lamp LED
Voltage: 100/240 V

Safety and Regulations

Not for general illumination
To wake up with light
UV-free

