



Philips Series 3200  
Fully automatic  
espresso machines

- 5 Beverages
- LatteGo
- Glossy Black
- Touch display

EP3241

## 5 delicious fresh bean coffees, easier than ever

### LatteGo, the fastest to clean milk system ever\*

Easily make aromatic coffee varieties like Espresso, Coffee, Cappuccino and Latte Macchiato at the touch of a button. LatteGo tops milk varieties with silky smooth froth, is easy to set up and can be cleaned in as little as 15 seconds\*

#### **A variety of coffees customized to your taste**

- Silky smooth milk froth thanks to high speed LatteGo system
- Enjoy 5 coffees at your fingertips, including cappuccino
- Easily adjust to your taste with 12-step grinder levels
- Adjust aroma strength and quantity via My Coffee Choice
- Easy selection of your coffee with intuitive touch display

#### **High quality coffee from fresh beans**

- Keep your beans fresh for longer thanks to the aroma seal
- 20,000 cups of finest coffee with durable ceramic grinders
- The perfect temperature, aroma and crema cup after cup\*\*

#### **Effortless use and cleaning for everyday enjoyment**

- Easy cleaning thanks to fully removable brew group
- Up to 5000 cups\*\*\* without descaling thanks to AquaClean
- LatteGo is exceptionally easy to clean: 2 parts, no tubes
- Dishwasher safe parts for your convenience

# PHILIPS

Fully automatic espresso machines  
5 Beverages LatteGo, Glossy Black, Touch display

EP3241/54

# Highlights

## 5 aromatic coffees



Enjoy your favourite coffees for your special moments. Whether you crave for an espresso, a coffee or a milk based recipe, your fully-automatic espresso machine delivers a perfect in-cup result with no hassle and in no time!

## LatteGo milk system



Top your coffee off with a silky-smooth layer of milk froth. By using cyclonic frothing technology, LatteGo releases a powerful stream of microbubbles at a speed of 394 metres per second, creating a rich and dense milk foam.

## Intuitive touch display

The irresistible taste and aroma of coffee from fresh beans is just one touch away. Our intuitive touch display allows you to easily select your favorite coffee.

## My Coffee Choice

Adjust the strength and quantity of your beverage with the My Coffee Choice menu. Easily choose from three different settings to suit your preferences.

## 12-step grinder adjustment



Our durable ceramic grinders can be adjusted in 12 steps, so you can turn your beans into anything from ultra-fine powder to coarse grindings.

## Perfect temperature and aroma



The Aroma Extract system intelligently strikes the optimum balance between brewing temperature and aroma extraction by keeping the water temperature between 90 and 98°C, while regulating the water flow rate, so you can enjoy delicious coffees.

## 100% ceramic grinders



Bring out the full flavor of your coffee with our hard-wearing ceramic grinder. Our sharp-edged grinders extract the best aroma and

flavour from your beans. Made from 100% ceramic material which ensures they last for at least 20.000 cups.

## 2 parts, no tubes milk system



Our 2 parts milk system has no tubes or hidden parts and can be cleaned in as little as 15 seconds under tap\* or in the dishwasher.

## AquaClean filter



By changing the filter after being prompted by the machine, you will not need to descale your machine for up to 5000 cups\*\*\*, while enjoying clear and purified water.

## Removable brew group



The brew group is the heart of every fully automatic coffee machine, and should be cleaned regularly. The removable brew group allows you to clean it thoroughly just by rinsing it under the tap.

# Specifications

## Country of origin

- Made in: Romania
- Designed in: Italy

## Customization

- Aroma Strength Settings: 3
- Grinder Settings: 12
- Coffee and Milk Length: Adjustable
- Pre Brew Aroma control
- Temperature settings: 3

## Variety

- Beverages: Espresso, Hot water, Cappuccino, Coffee, Latte Macchiato, Americano
- Coffee Powder Option
- Double Cup
- Milk Double Cup: No

## Other features

- Removable brew group
- Aroma Seal
- Guided descaling
- AquaClean

## Accessories

- Included: Measuring scoop, Water hardness test strip, AquaClean filter, LatteGo storage lid, Grease tube

## Technical specifications

- Voltage: 120 V

- Cord length: 100 cm
- Frequency: 60 Hz
- Capacity milk carafe: 0.26 L
- Capacity waste container: 12 servings
- Capacity water tank: 1.8 L
- Weight of product: 8 kg
- Coffee bean capacity: 275 g
- Waste container: Frontal access
- Water tank: Frontal access
- Filter compatibility: AquaClean
- Pump pressure: 15 bar
- Color & Finishing: Black, Glossy black
- Product dimensions: 246x371x433 mm

## General specifications

- Adjustable spout height: 85-145 mm
- Milk Solution: LatteGo
- Ease of cleaning & maintenance: AquaClean filter compatible
- Dishwasher safe parts: Drip tray, LatteGo
- User Interface: Touch screen display

## Service

- 2-year guarantee

## Sustainability

- ECO setting
- Energy label: A-class
- Power consumption brewing: 1500 W
- Recyclable packaging material: >95 %



Issue date 2024-01-15

Version: 3.3.1

UPC: 0 75020 08942 7

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* Based on consumer testing in Germany comparing leading One touch (Coffee + Milk) Full Automatic Espresso Machines (2018).

\*\*Based on 70-82 °C.

\*\*\*Based on 8 filters replacement as indicated by the machine. Actual number of cups depends on selected coffee varieties, rinsing and cleaning patterns.