

Philips Series 2200
Fully automatic
espresso machines

- 2 beverages
- Classic Milk Frother
- Matte black
- Touch display

EP2220/10



2 delicious coffees from fresh beans, with ease

Thanks to the intuitive touch display

Enjoy the delicious taste and aroma of coffee from fresh beans, at the perfect temperature, thanks to our intelligent brewing system. The classic milk frother allows you to create a silky smooth cappuccino or latte macchiato with ease.

A variety of coffees customized to your taste

- Delicious milk froth thanks to the classic milk frother
- Easily adjust to your taste with 12-step grinder levels
- Easy selection of your coffee with intuitive touch display
- Adjust aroma strength and quantity via My Coffee Choice

High quality coffee from fresh beans

- Keep your beans fresh for longer thanks to the aroma seal
- 20,000 cups of finest coffee with durable ceramic grinders
- The perfect temperature, aroma and crema cup after cup*

Effortless use and cleaning for everyday enjoyment

- Easy cleaning thanks to fully removable brew group
- Up to 5000 cups* without descaling thanks to AquaClean
- Dishwasher safe parts for your convenience
- Automatic descaling for your convenience

PHILIPS

Fully automatic espresso machines
2 beverages Classic Milk Frother, Matte black, Touch display

EP2220/10

Highlights

Classic milk frother



The Classic Milk Frother dispenses steam, allowing you to easily prepare silky smooth milk froth for your cappuccino. What's more? With only two parts, the Classic Milk Frother is also easy to clean.

Intuitive touch display



The irresistible taste and aroma of coffee from fresh beans is just one touch away. Our intuitive touch display allows you to easily select your favorite coffee.

My Coffee Choice



Adjust the strength and quantity of your beverage with the My Coffee Choice menu. Easily choose from three different settings to suit your preferences.

12-step grinder adjustment



Our durable ceramic grinders can be adjusted in 12 steps, so you can turn your beans into anything from ultra-fine powder to coarse grindings.

Perfect temperature and aroma



The Aroma Extract system intelligently strikes the optimum balance between brewing temperature and aroma extraction by keeping the water temperature between 90 and 98°C, while regulating the water flow rate, so you can enjoy delicious coffees.

100% ceramic grinders



Our grinders are 100% pure ceramic: extremely hard and precise, so you can enjoy fresh aromatic coffee, for at least 20.000 cups.

Preserve beans' aroma



The new Aroma seal protects your favorite coffee beans and makes sure they preserve their original aroma over time, while reducing the grinder noise.

AquaClean filter



By changing the filter after being prompted by the machine, you will not need to descale your machine for up to 5000 cups*, while enjoying clear and purified water.

Removable brew group



The brew group is the heart of every fully automatic coffee machine, and should be cleaned regularly. The removable brew group allows you to clean it thoroughly just by rinsing it under the tap.

Specifications

Country of origin

- Designed in: Italy
- Made in: Romania

Technical specifications

- Cord length: 100 cm
- Voltage: 230 V
- Frequency: 50 Hz
- Capacity water tank: 1.8 L
- Capacity waste container: 12 servings
- Coffee bean capacity: 275 g
- Weight of product: 7.5 kg
- Waste container: Frontal access
- Water tank: Frontal access
- Filter compatibility: AquaClean
- Pump pressure: 15 bar
- Color & Finishing: Black, Matte Black
- Product dimensions: 246x371x433 mm

General specifications

- Adjustable spout height: 85-145 mm
- Milk Solution: Classic Milk Frother
- Dishwasher safe parts: Classic milk frother, Drip tray
- Ease of cleaning & maintenance: AquaClean filter compatible
- User Interface: Touch screen display

Accessories

- Included: Grease tube, Measuring scoop, Water

hardness test strip, AquaClean filter

Customization

- Aroma Strength Settings: 3
- Grinder Settings: 12
- Pre Brew Aroma control
- Temperature settings: 3

Variety

- Beverages: Espresso, Hot water, Coffee
- Coffee Powder Option
- Double Cup
- Milk Double Cup: No

Other features

- Removable brew group
- Aroma Seal
- Guided descaling
- AquaClean

Service

- 2-year guarantee

Sustainability

- ECO setting
- Energy label: A-class
- Power consumption brewing: 1500 W
- Recyclable packaging material: >95 %



Issue date 2022-06-21

Version: 1.1.2

EAN: 08 71010 39534 32

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Based on 8 filters replacement as indicated by the machine. Actual number of cups depends on selected coffee varieties, rinsing and cleaning patterns.

* based on 70-82 °C