



Philips Daily Collection
Food processor

500 W
Compact 2 in 1 setup
2 L bowl



HR7625/70

Save space and effort

Ultra-compact food processor with blender

Save space, effort and time with the vertical-design Philips food processor HR7625/70. It's extremely powerful and superbly multi-functional so you can finish any preparation task in seconds! Including a blender.

Easy storage

- All accessories fit in the bowl for compact storage
- Vertical design takes up to 35% less kitchen space

Powerful precision

- 2 speeds and pulse
- 500 Watt motor to handle large quantities and heavy kneading
- Including blender
- Easily performs 25+ functions

PHILIPS

Food processor
500 W Compact 2 in 1 setup, 2 L bowl

Highlights

MicroStore



Microstore allows you to store all your accessories inside the bowl for easy and compact storage.

Vertical design

The special vertical design has a 35% smaller footprint versus side-by-side food processors. This saves valuable worktop space and means that even the smallest kitchens can now have a food processor.

2 speeds and pulse



The Philips food processor has two speed settings to match hard or soft ingredients. Plus, a pulse function for chopping garlic or crushing ice for example.

500 W motor + 2 speeds + pulse

500 W

With the 500W motor plus 2 speed settings and pulse button you can pick the right speed for optimal results

Including blender

The Food Processor comes with 7 accessories to perform 28 functions. They are: a stainless steel blade for chopping, beating, creaming, crumbling, cutting, folding in, mashing, mincing, mixing; a kneading tool for (heavy) kneading; a slicing insert for medium slicing of vegetables & fruit; a shredding insert for medium shredding of vegetables, fruit and cheese; an emulsifying disc for whipping, whisking, emulsifying; a granulating insert for granulating potatoes; and a blender for for blending, crushing, foaming, grinding, (heavy) pureeing, homogenizing, liquidizing, milling, shaking, stirring.

25+ functions



The Food Processor comes with 7 accessories to perform 25+ functions. The – dishwasher safe - accessories are a kneading tool for mixing batter and for heavy kneading. A stainless steel chopping knife to prepare meat and vegetables. Metal disk inserts to handle medium shredding and granulating. Break resistant blender of 1.5l for blending, crushing and stirring different ingredients. And an emulsifying disk to prepare food like whipped cream and mayonnaise.

HR7625/70

Specifications

Country of origin

- China

Technical specifications

- Cord length: 120 cm
- Power: 500 W, China: 460 W
- Color(s): Bright white and celestial blue
- Frequency: 50-60, China: 50 Hz
- Voltage: 220-240 V, China: 220 V
- Motor: Universal, radio/tv interference suppressed
- Blender volume capacity liquid: 1 L
- Bowl capacity dough: 830 g
- Bowl capacity dry: 2 L
- Speeds: 2+ pulse
- Bowl capacity flour: 500 g
- Safety: Safety lock system for lid & bowl detection, Mechanical brake on toolholder stops within 1.5sec
- Bowl volume capacity liquid: 1.2 L

Accessories

- Granulating insert medium: For granulating of potatoes, cheese
- Emulsifying disk: For whipping, whisking and emulsifying
- Kneading tool: For kneading and heavy kneading
- Stainless steel chopping knife: chopping, Beating, creaming, crumbling, cutting, folding in, mashing, mincing, mixing, kneading
- Blender: Blending, Homogenizing, Stirring, crushing, foaming, grinding, pureeing, heavy pureeing, liquidizing, milling, shaking
- Shredding insert medium: For medium shredding of vegetables, fruit, cheese
- Slicing insert medium: For medium slicing of vegetables and fruit
- Number of inserts/discs: 3

Design specifications

- Housing: ABS
- Bowl, cover, pusher: SAN & ABS
- Emulsifying disc: ABS
- Metal knife and inserts: stainless steel
- Switch and toolholder: ABS & POM
- Knife holder: PP & PET
- Blender jar knife holder: nylon 60
- Blender jar, cover and cup: SAN, PP
- Blender knife: stainless steel



Issue date 2021-11-11

Version: 1.1.1

EAN: 08 71010 33209 75

© 2021 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com