

Philips Daily Collection  
Food processor

**650 W**

2 speeds + pulse

2.1 L bowl

Accessories for + 15 functions

**HR7627/00**



## Maximum variety of recipes, minimum effort

Create home made breads, cakes, drinks and more

This Philips Daily collection Food Processor has a compact design including a 2.1 L bowl and a variety of high performance accessories. Preparing delicious homemade food has never been so easy!

### **Easiest assembly, use and cleaning**

- No mess from center of the bowl due to lack of inner shaft
- 40% larger feeding tube (compared to Philips HR7625)
- 650 Watt motor for powerful processing
- 2 speed settings and pulse for maximum control
- Dishwasher safe accessories

### **Maximum variety of recipes**

- Emulsifying tool for cream and egg whites
- Sharp and strong stainless steel S blade for chopping
- Up to 5 portions in one go
- High performance stainless steel disc inserts

### **Powerful precision**

- PowerChop technology for superior chopping performance

**PHILIPS**

Food processor  
650 W 2 speeds + pulse, 2.1 L bowl, Accessories for + 15 functions

HR7627/00

# Highlights

## 2 speed settings and pulse



For best results, use the low speed setting (speed 1) to whip cream, beat eggs, create pastries and bread dough. The higher speed setting (speed 2) is well suited to chop onions and meats, blend soups and smoothies or shred, slice, grate or rasp vegetables.

## 40% larger feeding tube



The new Philips Daily collection Food Processor comes with a feeding tube which is 40% larger than the previous HR7625 model, saving precutting time of fruits and vegetables

## Stainless steel disc inserts



Simply select the right stainless steel disc insert to prepare your favorite ingredient and click it

onto the disc holder. Performance has been tested extensively to provide the best slicing and shredding results.

## Powerful processing

# 650 W

This Philips Food Processor offers a powerful motor providing power and control to prepare all your favorite recipes.

## Up to 5 portions in one go



The generous 2.1L bowl (1.5 L working capacity) enables you to blend up to 5 portions of soup in one go.

## Dishwasher safe accessories



All accessory parts of your Philips food processor can be put on the top rack of your dishwasher for easy cleaning.

## Emulsifying tool



The perfect tool for whipping, whisking or emulsifying eggs or whipped cream. For best volume increase and fluffiness, use the low speed setting. Creating delicious desserts or mayonnaise has never been easier!

## PowerChop technology



## PowerChop

PowerChop technology is a combination of blade shape, cutting angle and inner bowl that provides a superior chopping result in both soft and hard ingredients. It is also perfect for making purées and mixing your cake batters!

# Specifications

## Accessories

- Included: Blade unit S-blade, Chopping knife, Emulsifying tool, Fine shredding tool, Fine slicing tool, Granulating tool

## Technical specifications

- Cord length: 1.0 m
- Voltage: 220-240 V
- Power: 650 W
- Capacity bowl: 2 L
- Working capacity bowl: 1.5 L
- Frequency: 50/60 Hz
- Capacity jar: 1.75 L
- Working capacity jar: 1.0 L
- RPM blender (max): 21000 rpm
- RPM bowl (max): 1900 rpm

## Design

- Color: White

## Weight and dimensions

- Dimensions of product (LxWxH):

244x244x377 mm

## General specifications

- Number of slicing disks: 3
- Number of speed settings: 2 + pulse
- Product features: Integrated cord storage, Non-slip feet, Pulse

## Finishing

- Material of main body: Plastic ABS
- Material accessories: Stainless steel
- Material jar: Plastic SAN

## Service

- 2-year worldwide guarantee

## Accessories included

- Fine shredding disk

## Sustainability

- Packaging: > 90% recycled materials
- User manual: 100% recycled paper



Issue date 2023-03-29

Version: 1.1.2

EAN: 87 10103 66513 7

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)