



Philips  
Air purifier

Sleep mode

AC4025/01

# A healthier sleep, always

Purifier with dedicated Sleep mode

Breathe healthy air with the Philips air purifier. Its advanced filtration system filters out bacteria, allergens and harmful agents. The Healthy air protect alert assures you of healthy air always.

## **Always**

- Healthy air protect alert warns you when to replace filter

## **Healthy Air**

- Sleep mode cleans silently with dimmed indicators
- With advanced filtration system

## **Simplicity**

- 1/4/8 hours easy-to-set timer

## **Simplicity**

- 3-step fan speed lets you adjust air flow to your liking

# PHILIPS

# Highlights

## Advanced filtration system

The advanced filtration system eliminates harmful agents in two stages: In stage 1, the activated carbon filter acts as pre-filter to catch big particles like human hair and regular house dust, and effectively removes odors and harmful gases. In stage 2, the HEPA filter filters out fine dust, bacteria and allergens.

## Sleep mode



This Philips purifier operates very quietly and dimmed lights, to allow you to sleep undisturbed. The purifier switches to lower activity level, the fan speed and noise level are reduced and the energy consumption is minimised.

## Healthy air protect alert



Healthy air protect alert gives you a timely warning when to replace the filter. When the filter is not

replaced in time, the appliance stops functioning to avoid running with no effect since filter is full. It is your assurance of healthy air always.

## 3-step fan speed



3-step fan speed lets you adjust air flow to your liking.

## 1/4/8 hours easy-to-set timer



Appliance operates for a set number of hours and automatically switches off when set time has elapsed.

# Specifications

## Design specifications

- Materials of main body: ABS plastic
- Front cover: white
- Rim: green

## Logistic data

- Country of origin: China
- 12NC code: 883402501500 (Malaysia/ Singapore)
- EAN F-box: 8710103635581 (Malaysia/Singapore)

## Interactivity

- Frequency: 50 Hz
- Voltage: 220-240 V
- Cord length: 1.8 m
- Noise level: 36 (Sleep) - 54 (Highest speed) dB
- Wattage: 30 W

## Weight and dimensions

- Product weight: 4.5 kg
- Product dimensions (W x D x H): 333 x 186 x 510 mm
- F-box weight (incl. product): 6.1 kg
- F-box dimensions (W x D x H): 421 x 273 x 605 mm

## Replacement

- AC filter: AC4103
- HEPA filter: AC4104

## Performance

- CADR (cigarette smoke): 147 m<sup>3</sup>/h\*\*
- Filters out PM2.5: >99% \*\*\*
- Filters out bacteria: >99.9% \*\*\*\*



Issue date 2023-04-24

Version: 1.1.2

EAN: 87 10103 63558 1

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\*\* Tested by Shanghai Institute of Measurement and Testing Technology (SIMT) in 30m<sup>3</sup> chamber according to GB/T18801-2008, cigarette smoke used as the particle pollutants

\*\*\* Tested by SIMT in 30m<sup>3</sup> chamber according to GB/T18801-2008 and GB/T18883-2002, inhalable particles of size smaller than 2.5µm as particles pollutants sampled in mass concentration, initial concentration 5.0;A0.5mg/m<sup>3</sup>, testing time 1hr

\*\*\*\* Tested by Shanghai Institute of Measurement and Testing Technology (SIMT) in 30m<sup>3</sup> chamber according to GB21551.3-2010, (Staphylococcus albus) 8032 as testing bacteria