

Philips Daily Collection
Meat mincer

450W nominal

1600W blocked power
1.7kg/min

HR2710/10



High performance mincing, ultra-compact design

Superior motor for up to 1.7kg/min mincing

This compact Philips Meat Mincer is designed to save you significant amount of kitchen space both during usage and storage. At the same time, thanks to its sturdy motor and metal coupling, you can mince high quantities of meat.

Effortlessly easy

- Innovative 2 sided cleaning tool
- Easy self feeding for effortless mincing
- Easy to carry thanks to the integrated handle
- Self-correcting knife and screw for always correct assembly

Powerful precision

- Mincing capacity up to 1.7kgs in 1 minute
- 2 hygienic stainless steel grinding discs (5, 8 mm)
- Strong motor with 450W nominal and 1600 W blocked power

Reliably durable

- Full metal coupling for heavy duty performance
- Hygienic stainless steel cutting knife stays sharp
- Motor protection device

PHILIPS

Meat mincer
450W nominal 1600W blocked power, 1.7kg/min

HR2710/10

Highlights

Powerful motor



450W nominal, 1600W blocked power for mincing quick and easy.

High capacity



Mincing capacity up to 1.7kgs in 1 minute.

2 stainless steel discs



2 hygienic stainless steel grinding discs (5, 8 mm)

Full metal gear coupling



The full metal gear coupling is designed to withstand heavy duty mincing.

Hygienic stainless steel knife



Hygienic stainless steel cutting knife stays sharp.

Motor protection device

TCO motor protection for long product lifetime.

Innovative cleaning tool



Innovative 2 sided cleaning tool shortens cleaning time with 50%. After mincing, simply click the mincing screen onto the cleaning tool and rinse under running water. No more tedious cleaning of clogged screen holes!

Easy self feeding

Easy self feeding for effortless mincing.

Self-correcting parts

The knife can only be assembled correctly on the feeding screw.

Integrated handle

Easy to carry thanks to the integrated handle.

Specifications

Technical specifications

- Power: 1600 W
- Cord length: 1.0 m
- Frequency: 50 Hz

Design and finishing

- Material of main body: ABS plastic
- Color(s): White/Caribbean Blue

- Material of accessories: Stainless steel
- Material blade: Stainless steel

General specifications

- Number of speed settings: 1

Accessories

- Included: Cleaning tool



Issue date 2021-12-18

Version: 1.1.1

© 2021 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com