



**Saeco GranBaristo Avanti**  
Super-automatic espresso machine

- 18 Beverages
- Integrated milk carafe
- Stainless Steel
- AquaClean



HD8967/47

## The most advanced at-home coffee experience

Enjoy 18 drinks simply prepared from your tablet\*

Saeco GranBaristo Avanti offers a variety of 18 irresistible drinks. Each drink can be customized exactly to your taste and brewed directly via your smart device. The maintenance is super easy with the step by step guidance via the App\*.

### Any coffee for any moment

- Enjoy 18 beverages at your fingertips
- Adjust the length, 6 aroma strength and 5 grinder settings
- One-touch Cappuccino and Latte Macchiato with milk carafe
- Adjust and store up to 6 user profiles

### Attentive and anticipating at your command

- Enhanced control of your machine via the advanced display
- Customize and save each drink easily via the App
- One-finger removable brewing group for an effortless clean
- Clean milk residues after every use with milk clean function


### Every coffee crafted to perfection

- Iconic stainless steel finishing, shaped to precision
- Variable brewing pressure for coffee and espresso

### Every coffee crafted to perfection

- 20,000 cups of finest coffee with durable ceramic grinders

**Saeco**



# Highlights

## 18 beverages

Enjoy an unparalleled variety of drinks to suit any occasion. Whether you crave for an espresso, a coffee or a milk based recipe, your Super-automatic machine delivers a perfect in-cup result with no hassle and in no time!

## Integrated milk carafe



Enjoy super creamy cappuccino and Latte Macchiato at the perfect temperature, in the easiest way possible. Simply pour milk into the carafe, plug it into the machine, and select your preferred beverage. Whether it's a cappuccino or frothed milk, your drink will be served within seconds, with a splash-free flow at the ideal temperature.

## Customize your coffees



This Super-Automatic machine offers an abundance of indulgent options to customize

your beverage to your taste. You can easily personalize and memorize length, strength and temperature for each drink. Feel free to explore, experiment and dream up any drink!

## User Profiles



Store your personal coffee settings in the easily accessible personal user profiles. You will be able to drink espresso, coffee, cappuccino and all other drinks always as you prefer, at the touch of a button.

## 100% ceramic grinders



Our grinders are made of high-tech ceramic: exceptionally hard and precise. Fresh beans are gently ground, without risk of overheating: extracting all the best flavors and aroma, delivering a superior coffee taste for at least 20,000 cups.

## Latte Perfetto Technology



Every coffee you prepare will be topped with a silky, milk layer that beckons the taste buds. The milk carafe froths the milk twice, then pours a splash free creamy layer into your cup at just the right temperature. The carafe can also be stored conveniently in the fridge and it is incredibly hygienic.

## VariPresso Technology



The Saeco GranBaristo offers an unparalleled variety of drinks to suit any occasion thanks to the patented VariPresso brewing chamber. The secret is in the adjustable brewing pressure; set it on high for an intense, rich espresso, or lower the pressure for a long, classic coffee.

# Specifications

## Technical specifications

- Cord length: >100 cm
- Voltage: 120 V
- Frequency: 60 Hz
- Capacity milk carafe: 0.5 L
- Capacity water tank: 1.7 L
- Capacity waste container: 20 servings
- Coffee bean capacity: 270 g
- Weight of product: 13 kg
- Waste container: Frontal access
- Water tank: Access from the top
- Max. cup height: 165 mm
- Filter compatibility: Brita Intenza
- Color & Finishing: Stainless Steel
- Product dimensions: 205 x 360 x 460 mm

## General specifications

- Milk Solution: Integrated Milk Carafe, Quick Milk clean

## Customization

- Aroma Strength Settings: 6
- Grinder Settings: 5
- Coffee and Milk Length: Adjustable

- Pre Brew Aroma control
- User Profiles: 6
- Temperature settings: 3

## Variety

- Beverages: Café au Lait, Caffè crema, Cappuccino, Energy coffee, Espresso, Espresso Lungo, Espresso Macchiato, Hot water, Latte Macchiato, Milk froth, Ristretto
- Brewing group: Varipresso Technology
- Coffee Powder Option
- Double Cup
- Milk Double Cup: No

## Other features

- Auto-Rinse & Guided descaling
- Removable brew group
- Gusto perfetto
- Main Switch ON / OFF button
- Quick Heat Boiler

## Service

- 1-year guarantee