



**Saeco Incanto
Super-automatic
espresso machine**

- 4 Beverages
- Classic Milk Frother
- Black
- 5 step adjustable grinder



HD8911/47



Elegant design. Impressive coffee quality.

Advanced technology delivering maximum flavor

The Saeco Incanto has set a new standard in its class. The strikingly refined casing houses high-quality Italian technology, engineered to brew divine coffee, every time. Your coffee dreams have finally been answered.

A variety of coffees customized to your taste

- Decaffeinated with equal zest with the Powder Option

A variety of coffees customized to your taste

- The strength selection remembers just how strong you like it

High comfort is part of the experience

- Designed for efficiency
- Auto-cleaning cycle removes any hassle


Advanced technology designed for coffee perfection

- Velvety milk foam with the Classic Milk Frother

High comfort is part of the experience

- The fully removable brewing group can be cleaned in no time

 **Saeco**



Highlights

100% Ceramic grinders



Our grinders are made of high-tech ceramic: exceptionally hard and precise. Fresh beans are gently ground, without risk of overheating: extracting all the best flavors and aroma, delivering a superior coffee taste for at least 20,000 cups.

Quick Heat Boiler



When time is of the essence, you can brew perfect espresso and cappuccino without the wait, thanks to the Quick Heat Boiler. The secret is in its light aluminum and stainless steel body, which can reach hot temperatures, fast.

Classic Milk Frother



The Classic Milk Frother is for those who love to assume the role of master craftsman, and it's just easy. Within seconds you can create a rich, silky layer of foam - the crowning glory of your coffee.

Powder Option



Sometimes it's nice to have the option of a full-bodied, delicious coffee, without the caffeine kick. Thanks to the Powder Option you can make decaffeinated coffee whenever you please.

Designed for efficiency



Saeco Incanto ingeniously combines efficiency with attentiveness to meet the highest standards for your home – keeping water consumption and energy usage low. And with the programmable stand-by, just tell the Saeco Incanto when it won't be needed and it will switch itself off automatically. Easy.

Auto-cleaning



The automatic cleaning cycle makes it easy to look after, and it increases the machine's longevity – giving you more time to enjoy your coffee instead of cleaning up.

Specifications

Country of origin

- Made in: Europe

Accessories

- Included: Water filter

Technical specifications

- Voltage: 230 V
- Capacity bean container: 250 g
- Cord length: 0.8 m
- Brewing time one cup: 45 (espresso) to 100 (long coffee) s
- Frequency: 50 Hz
- Capacity water tank: 1.8 L
- Capacity waste container: 15 servings
- Max. cup height: 152 mm
- Water boilers: 1
- Pump pressure: 15 bar

Design

- Color: Black

Weight and dimensions

- Dimensions of product (WxDxH): 215 x 429 x 330 mm
- Weight of product: 7.2 kg

General specifications

- Cups at the same time: 2
- Suitable for: Whole coffee beans, ground coffee powder

- Coffee strength settings: 5
- Ease of cleaning & maintenance: Automatic descaling cycle, Automatic rinse cycle, Removable brewing group
- Customizing per drink: Adjustable coffee strength, Adjustable cup volume, Adjustable temperature
- Grinder settings: 5
- Ease of use and comfort: Removable spout, Automatic stand-by, Display, Removable drip-tray, Removable water tank, Automatic shut-off
- Temperature settings: 3
- Special functions: Ceramic grinder, Hot water option, Manual milk frother Pannarello, Ground coffee option, Steam option
- Type of display: LCD
- Coffee drinks: Espresso, Espresso Lungo, Milk Froth, Hot Water

Finishing

- Material of main body: Plastic
- Material boiler: Stainless steel (Inox)
- Material drip tray: Stainless steel
- Material water tank: Plastic
- Material panarello: Stainless steel

Service

- 1-year guarantee

Sustainability

- Power consumption brewing: 1850 W



Issue date 2023-08-22

Version: 1.1.1

UPC: 0 75020 06054 9

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Based on 8 filters replacement as indicated by the machine. Actual number of cups depends on selected coffee varieties, rinsing and cleaning patterns.