



Saeco Xsmall  
Vapore Super-  
automatic espresso  
machine

- 3 Beverages
- Classic Milk Frother
- Black



HD8645/47

## Taste the aroma of your favourite coffee beans

### One touch super-automatic espresso machine

Whatever blend of coffee you wish to try next, the Xsmall will grind the beans fresh on the spot at the touch of a button. It comes also equipped with a manual frother to add a touch of velvety pleasure to all your fresh coffee drinks.

#### **Your fresh coffee experience**


- 20,000 cups of finest coffee with durable ceramic grinders
- Always the right strength in cup, no matters which beans
- Hot coffee from the first cup with Thermoblock

#### **A variety of coffees customized to your taste**

- Enjoy 3 beverages at your fingertips
- Delicious milk froth thanks to the classic milk frother
- Adjust the length and 5 grinder settings
- Enjoy 2 cups at the same time with Double Cup function
- Adjust and store your personal user profile

#### **Enjoy your coffees every day with no hassle**

- Enjoy a great coffee with Auto-Rinse & guided descaling
- Thorough cleaning thanks to fully removable brewing group
- Fits any kitchen thanks to the small size and frontal access

# Highlights

## 3 beverages



Enjoy your favourite drinks for your special moments. Whether you crave for an espresso, a coffee or a milk based recipe, your Super-automatic machine delivers a perfect in-cup result with no hassle and in no time!

## Auto-Rinse & Guided descaling



This espresso machine automatically cleans its coffee circuit with water upon starting up or switching off of the machine, this delivers a great, fresh taste with each cup of coffee. Regular descaling prolongs your espresso machine's life. This machine will prompt when descaling is needed. It will guide you with on-screen messages what you have to do and when.

## Classic milk frother



The Classic Milk Frother, which baristas also call Pannarello, dispenses steam to help you easily prepare soft milk foam for your cappuccino. Unleash your inner barista by preparing your delicious milk specialties the traditional way!

## Customize your coffees

Adjust the length and 5 grinder settings

## Double Cup

Enjoy and share your favorite coffee thanks to the double cup function

## Removable brew group



The brewing group is the heart of every super-automatic coffee machine, and should be cleaned regularly. The fully removable brewing group allows you to clean it thoroughly just by rinsing it under the tap

## Small size and frontal access

It doesn't matter how big your kitchen is: this machine fits even the smallest spaces, and it is extremely convenient as you can access the water and waste containers from the front. Designed for making your coffee enjoyment easier.

## User Profiles

Store the length of any coffee beverage according to your personal taste. You will be able to drink espresso, coffee and all other beverages always as you prefer, at the touch of a button.

## 100% ceramic grinders



Our grinders are made of high-tech ceramic: exceptionally hard and precise. Fresh beans are gently ground, without risk of overheating: extracting all the best flavors and aroma, delivering a superior coffee taste for at least 20,000 cups.

## Gusto perfetto

Gusto Perfetto is self learning technology that tracks constantly the beans you use to prepare your drinks. If it detects a change in the type of beans used, it automatically adjust the dosing in the brew chamber to always ensure a consistent result in cup

# Specifications

## Customization

- Aroma Strength Settings: No
- Coffee Length: Adjustable
- Grinder Settings: 5
- Pre Brew Aroma control: No
- User Profiles: 1

## Variety

- Beverages: Espresso, Espresso Lungo, Hot water
- Coffee Powder Option: No
- Double Cup
- Milk Double Cup: No

## Other features

- Auto-Rinse & Guided descaling
- Removable brew group
- Gusto perfetto
- Main Switch ON / OFF button
- Quick Heat Boiler

## Technical specifications

- Voltage: 120 V
- Cord length: <100 cm
- Frequency: 60 Hz
- Capacity water tank: 1 L
- Capacity waste container: 8 servings
- Coffee bean capacity: 180 g
- Waste container: Frontal access
- Water tank: Frontal access
- Max. cup height: 95 mm
- Filter compatibility: Brita Intenza
- Product dimensions: 295 x 325 x 420 mm

## General specifications

- Milk Solution: Classic Milk Frother
- User Interface: LED Buttons

## Service

- 1-year guarantee



Issue date 2023-08-22

Version: 1.1.2

UPC: 0 75020 04770 0

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)