

750 W



Philips Daily Collection  
Mixer Grinder

750 W

3 stainless steel jars  
Black & Grey

HL7756/00

## Grind more, cook more

with 25 minutes continuous grinding\*

Philips Mixer Grinder offers newly designed 750W Turbo motor with advanced air ventilation system that gives you the confidence of break down free continuous 25 minutes grinding experience even with tough ingredients like black gram(dal)

### Easy cleaning

- Unique triangular body design

### Continuous 25 Min grinding

- Advanced air ventilation system
- Durable coupler
- Powerful 750W Turbo motor

### Easy grinding with 3 different jars

- Food-grade and high quality stainless steel jars
- Specialized blades for smooth grinding
- Leak proof jars

# PHILIPS

# Highlights

## 750W Turbo Motor



Newly designed powerful Turbo motor for continuous grinding - 750W Turbo motor that gives you the grinding experience even with tough ingredients like Black whole gram (dal) for preparing tasty Vadas and Dosas.

## Advanced Air ventilation



The advanced air ventilation system provides faster cooling of the appliance which ensures longer life of the motor.

## Durable coupler



The coupler is made of tougher plastic material for firm engagement between the jars and the

body which ensures continuous grinding performance; while you focus on your cooking.

## Food-grade rust-free jars



Food-grade high quality stainless steel jars enable grinding of batters, purees and pastes milkshakes and lassis in the same jar. The semi-dome transparent lid allows you to see the ingredients for perfect consistency to suit your way of cooking.

## Specialised blades



Specialized blades helps to cut even the toughest ingredients and gives the finest paste and smoothest shakes and purees for daily cooking especially for smooth grinding preparation of chutneys, dips, masalas and pastes

## Leak proof jars



Specially designed rubber gaskets for the lids of wet and chutney jars that guarantee a tight fit and smooth and secure locking.

## Unique triangular body



Unique triangular compact shaped body with less grooves for easy cleaning.

# Specifications

## Weight and dimensions

- Dimensions of packaging (LxWxH): 360 x 220 x 270 mm
- Dimensions of product (LxWxH): 190 x 190 x 210 mm
- Weight incl. packaging: 4.1 kg
- Weight of product: 3.2 kg

## Country of origin

- Made in: India

## General specifications

- Non-slip feet
- Type of filling: Lid
- Type of lid: Removable
- Number of speed settings: Pulse + 3 speed
- Pulse
- Overload protection

## Accessories

- Included: Jar

## Design

- Color: Black & grey

## Technical specifications

- No. of Jars: 3
- Cord length: 1.2 m
- Voltage: 230 V
- Power: 750 W
- Frequency: 50 Hz
- Capacity jar: 1.5 / 1 / 0.3 L
- Working capacity jar: 0.6 / 0.5 / 0.2 L
- RPM Motor- No load: 23000 rpm
- RPM Motor -With load: 13400 rpm
- Jars specifications: 3 Stainless Steel Jars

## Sustainability

- Packaging: <gt; 90% recycled materials
- User manual: 100% recycled paper

## Service

- 2-year product Warranty



Issue date 2023-03-07

Version: 3.3.1

EAN: 87 10103 76047 4

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)