



Philips Daily Collection
Kettle

1.0 L, 2000W

Titanium
Compact
Kettle



HD9349/12

Compact size, made to last

Stainless steel and sealed, guaranteed no leaks

With over 60 years of kettle expertise, this Philips kettle is made of sturdy, food contact safe stainless steel to assure long lifetime. We designed it to be highly robust to endure frequent use on the long term.

Fast boiling and easy cleaning

- Flat heating element for fast boiling and easy cleaning
- Robust metal kettle with brushed stainless steel body
- Micro-mesh filter for a clean cup of water

Safe to use

- Multiple safety system against boil-dry
- Food contact safe stainless steel

Easy to experience

- Pilot light indicates when the kettle is switched on
- Cordless 360° pirouette base for easy lifting and placing.
- Compact design to boil only the water you need
- Spring lid for easy opening
- Power cord winder for easy storage
- Easy-to-read water level indicator denoting cup volumes

PHILIPS

Highlights

Pilot light



Elegant light incorporated in the on/off switch indicates when the kettle is on.

Flat heating element



The stainless steel concealed element ensures fast boiling and easy cleaning.

Cordless 360° pirouette base



Cordless 360° pirouette base for easy lifting and placing.

Compact design



Enables you to boil the amount of water you need in a quicker way, whilst occupying less space from your countertop.

Micro-mesh filter



The removable micro-mesh filter on the spout restrains all scale particles with size > 200 micron and ensures that the water you put into your cup is clean.

Food contact safe material

This kettle is made of food contact safe stainless steel for your clean cup of water.

Multiple safety system



The kettle shuts off automatically when the water is ready, when it is lifted from the base or when there is too little water in it in order to avoid boil-dry.

Spring lid



Spring opening lid opens effortlessly at the touch of a button, also avoiding steam contact

Power cord winder



The cord can be wrapped around the base, so that the kettle is easy to place in your kitchen.

Water level indicator



The water level indicator is easy to read underneath the handle. One cup indicator to boil the amount of water you need, and therefore save energy and water, contributing to a better environment

Robust metal kettle

Robust metal kettle with brushed stainless steel body is made to have a long lifetime.

Specifications

Country of origin

- Made in: China

Weight and dimensions

- Weight of product: 0.97 kg
- Dimensions of packaging (LxVxH): 185 x 250 x 205 mm
- Weight incl. packaging: 1.31 kg
- Micromesh filter: 200 µm

Technical specifications

- Power: 2000 W
- Cord length: 0.75 m
- Voltage: 220-240 V
- Frequency: 50-60 Hz
- Capacity jar: 1 L

General specifications

- Product features: 360 degrees base, Automatic shut-off, Boil-dry protection, Cord storage, Flat heating element, Non-slip feet, On/off switch, Power-on light, Lid and spout filling, Spring lid

Design

- Color: Titanium

Finishing

- Material of main body: Stainless steel
- Material heating element: Stainless steel
- Material switch: PP plastic

Service

- 2-year worldwide guarantee



Issue date 2022-01-16

Version: 1.1.1

EAN: 08 71010 37968 31

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com