



Philips Daily Collection
Kettle

1.5 L

2200 W
Plastic

HD9334/12

Stylish design, made to last

See-through design helps you boil what you need

This smartly designed kettle allows you to read the amount of water from any angle while effectively filtering out lime scale thanks to the Micro-mesh filter. Reliable and efficient boiling, long life time!

Fast boiling and easy cleaning

- Removable lid for easy reach during cleaning
- Micro-mesh filter for a clear cup of water
- Flat heating element is easy to clean

Safe to use

- Steam leak-proof design for lid, handle and switch
- Multi safety system

Easy to experience

- 360° intuitive water level indicator
- Cordless 360° pirouette base for easy lifting and placing
- Power cord winder for easy storage

PHILIPS

Kettle
1.5 L 2200 W, Plastic

HD9334/12

Highlights

360° water level indicator



Easy to read water level indicator from every angle due to the translucent body. The stylish stripes smartly indicate the water and cups amount as well.

Cordless 360° pirouette base



Cordless 360° pirouette base for easy lifting and placing.

Power cord winder



The cord can be wrapped around the base, so that the kettle is easy to place in your kitchen.

Removable lid



Fully removable lid for easy reach during cleaning.

Micro-mesh filter



The removable fine micro-mesh filter on the spout restrains all scale particles with size > 180 micron and ensures that the water you put into your cup is clean.

Flat heating element



The stainless steel concealed element ensures fast boiling and easy cleaning.

Steam leak-proof



Steam leak-proof design for lid, handle and switch, avoiding steam contact.

Multi safety system



Multiple safety system against boil-dry, with auto switch off when ready or when lifted from the base.

Specifications

Country of origin

- Made in: China

Design

- Color: Star White and Caribbean Blue

Technical specifications

- Cord length: 0.75 m
- Power: 2200 W
- Capacity bowl: 1.5 L
- Voltage: 220-240 V
- Frequency: 50/60 Hz

Service

- 2-year worldwide guarantee

Weight and dimensions

- Dimensions of product (LxWxH):
223x162x254 mm
- Micromesh filter: 180 µm

General specifications

- Product features: 360 degrees base, Automatic shut-off, Boil-dry protection, Cord storage, Flat

heating element, Integrated cord storage, Non-slip feet

Consumer Trade Item

- Height: 25.2
- Width: 22.6
- Length: 19.2
- Net Weight: 1.056
- Gross Weight: 1.426
- GTIN: 08710103742258
- Country of origin: CN
- Harmonized system code: 851610

Outer Carton

- Height: 53
- Width: 24.4
- Length: 59.6
- Gross Weight: 9.47
- GTIN: 18710103742255

Finishing

- Material of main body: PP Plastic
- Material heating element: Stainless steel
- Material switch: PP Plastic



Issue date 2023-03-16

Version: 1.1.1

EAN: 87 10103 74225 8

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com