



Philips Avance Collection  
Juicer

**QuickClean**  
1200W  
XXL feeding tube



HR1922/21

## Fresh juice with the fiber you like

Choose up to 50% extra fiber

FiberBoost technology enables you to choose the texture of juice you prefer, selecting with the switch of a button from a refreshing clear juice to a more creamy juice with up to 50% more fiber.

### Clean in 1 minute with QuickClean Technology

- Dripstop for clean kitchen counter
- Easy to clean sieve
- Just pour in water for quick pre-cleaning
- Pulp naturally falls into one container

### Fresh juice at your convenience

- XXL feeding tube (80mm)
- More silent
- Powerful 1200W motor

### Choose the texture of juice you prefer

- FiberBoost Technology with up to 50% extra fiber

**PHILIPS**

# Highlights

## FiberBoost technology



FiberBoost technology enables you to choose the texture of juice you prefer, selecting with the switch of a button from a refreshing clear juice to a more creamy juice with up to 50% more fiber. The unique combination of smartly controlled constant speeds with unique sieve design allows more or less fiber in your juice, so that everyone can enjoy their favorite.

## Easy to clean sieve



Thanks to the polished sieve it is very easy to clean up away leftovers with a kitchen sponge.

## More silent



The new motor has a lower noise and vibration which make the overall juicing experience more silent.

## Pre-clean



Philips' unique pre-clean function allows you to quickly rinse clean your juicer between different juices or after juicing. By pouring water into the pusher, you can create a water fountain rinsing away unwanted leftovers.

## Pulp in one place



Due to the round shape without nooks and crannies the leftovers is collected in the pulp container.

## Dripstop



The integrated drip stop allows you to stop between juicer sessions keeping your counter top spotless. Activate the drip stop by simply turning the spout.

## XXL feeding tube



Save time and start juicing faster. You no longer need to cut up most fruit and vegetables to fit this juice machine. Just pop it all into the 80mm XXL feeding tube, and enjoy a boost of nutrition every day.

## Powerful 1200W motor

Juice the toughest fruits and vegetables effortlessly with the strong 1200W motor.

# Specifications

## Country of origin

- Made in: China

## Accessories

- Included: Jug, Recipe booklet

## Technical specifications

- Power: 1200 W
- Cord length: 1 m
- Voltage: 220-240 V
- Capacity jar: 1 L
- Capacity pulp container: 2.1 L

## Design

- Color: Metallic

## Weight and dimensions

- Dimensions of product (LxWxH): 296 x 250 x 432 mm
- Dimensions of packaging (LxWxH): 550 x 320 x 330 mm

330 mm

- Weight incl. packaging: 4.7 kg
- Feeding tube diameter: 80 mm

## General specifications

- Number of speed settings: 2
- Product features: Dishwasher safe, Integrated cord storage, Non-slip feet, Quickclean

## Finishing

- Material of main body: Metal
- Material jug: SAN

## Service

- 2-year worldwide guarantee

## Sustainability

- Packaging: > 90% recycled materials
- User manual: 100% recycled paper



Issue date 2023-08-14

Version: 3.3.1

EAN: 87 10103 77741 0

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)