



Philips Azur Elite  
Steam Iron with  
OptimalTEMP technology

**3000 W**

75 g/min continuous steam  
260 g steam boost  
SteamGlide Advanced soleplate



**GC5039/30**

## Our smartest and most powerful steam iron

Guaranteed no burns, with intelligent steam release

Powerful, intelligent steam iron for perfect results faster. Iron everything from jeans to silk with no risk of burning thanks to OptimalTEMP technology. Advanced DynamiQ steam mode ensures the perfect amount of powerful steam when you need it.

### Comfortable ironing

- SteamGlide Advanced soleplate, ultimate gliding and durability
- Smart calc reminder to remove calc from the iron
- Quick Calc Release in 15s for long-lasting steam performance
- Extra long cord for maximum reach
- Automatic shut-off when the iron is left unattended

### Intelligent ironing for ultimate convenience

- OptimalTEMP technology: Guaranteed no burns, no settings
- Convenient steam modes: DynamiQ, MAX, IONIC and OFF
- DynamiQ mode, intelligent steam release for perfect results
- Ionic steam mode, deep ionised steam for hygienic ironing

### Easier and faster ironing

- 3000 W for quick heat-up and powerful performance
- Up to 260 g steam boost blasts stubborn creases
- Turbo steam pump pushes up to 50% more steam through fabric\*

**PHILIPS**

# Highlights

## OptimalTEMP technology



Thanks to OptimalTEMP technology, we guarantee this iron will never cause burns to any ironable fabric and you can iron everything from jeans to silk, from linen to cashmere safely, in any order, without waiting for the temperature to adjust or pre-sorting clothes. Philips steam irons with OptimalTEMP make your ironing easier and faster and have been tested by independent textile experts.

## DynamiQ steam mode



Thanks to DynamiQ sensor, the most advanced motion sensor used in steam irons knows precisely how your iron is moving and when it's standing still. DynamiQ steam mode automatically releases the perfect amount of steam when needed during ironing to get results faster. The steam automatically starts when your iron is moving and stops when you stop, for the ultimate in convenience and effortless ironing.

## Convenient steam modes



Choose from multiple steam modes. DynamiQ mode automatically delivers the perfect amount of steam when you need it, Max mode blasts stubborn creases with powerful continuous steam, IONIC mode uses powerful bursts of steam for more hygienic ironing and OFF mode enables you to switch off the steam

## Deep Ionic Steam



Ionic Steam mode produces deep and powerful ionic steam bursts for more hygienic ironing for your specific garment needs.

## 3000 W for fast heat-up



Delivers a fast warm-up and powerful performance to get your ironing done quickly

## SteamGlide Advanced soleplate



Our superior SteamGlide Advanced soleplate delivers smooth gliding performance on any fabric. Its stainless steel base is twice as hard as aluminium, and our patented 6-layer coating with its advanced titanium layer effortlessly glides on any fabric for the fastest results.

## Extra long cord



An ultra-long 3-metre cord provides maximum reach and convenience.

## Turbo Steam power



Our built-in Turbo Steam pump delivers up to 50% more powerful continuous steam so creases disappear faster.

# Specifications

## Easy to use

- Water tank capacity: 350 ml
- Soleplate name: SteamGlide Advanced
- Drip-stop
- Extra-stable heel rest
- Extra-large filling hole
- Auto shut-off

## Fast crease removal

- Power: 3000 W
- Continuous steam: 75 g/min
- Steam boost: 260 g
- Vertical steam
- Ionic Deep Steam

## Scale management

- Descaling and cleaning: Quick Calc Release

## Size and weight

- Product dimensions (W x H x D): 33,3 x 17,5 x 13,5 cm

## Green efficiency

- Energy saving mode
- User manual: 100% recycled paper

## Comfortable ironing

- Cord length: 3 m

## Guarantee

- 2 year worldwide guarantee



Issue date 2022-02-04

Version: 2.2.1

EAN: 08 71010 38310 51

© 2022 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* On all ironable fabrics  
\* Compared to GC4910