



Philips
PSG_PC_6000Series
Steam Generator Iron

Powerful steam

Guaranteed no burns*
1.8 L detachable water tank
Compact



PSG6066/26

Ultra fast. Extra Compact.

PerfectCare 6000 Series is designed to deliver the best steam performance, now in a fully renewed, compact design. Enjoy ironing faster without compromising on your storage space. With no burns guaranteed* thanks to OptimalTEMP technology.

Effortless ironing with great results

- OptimalTEMP technology, no burns guaranteed*

Powerful performance

- Powerful steam for crease removal
- SteamGlide Advanced soleplate, ultimate gliding and durability
- Easy De-Calc to extend the lifetime of your iron

Extra convenient to use

- Lightweight and compact for easy use and storage
- 1.8 L detachable water tank for easy refilling
- Automatic shut-off when iron is left unattended
- Safe-carry lock for safe and easy transport

PHILIPS

Specifications

Weight and dimensions

- Weight of iron: 1.2 kg
- Product dimensions (W x H x D): 16.8 x 26.9 x 36.8 cm
- Packaging dimensions (W x H x D): 22.7 x 34.2 x 43.0 cm
- Weight of iron + base: 3.2 kg

General specifications

- Hose storage: Compartment
- Power cord storage: Velcro fix
- Safety carry Lock
- Auto shut-off

Technology

- OptimalTEMP technology
- ProVelocity steam engine

Accessories

- Calc Clean container

Fast crease removal

- Pressure: 8 bar

- Power: 2400 W
- Continuous steam: 130 g/min
- Steam boost: Up to 600 g
- Vertical steam
- Voltage: 220-240 V

Limescale management

- Calc clean solution: Smart Calc Clean
- Suitable for tap water
- Calc clean reminder

Green efficiency

- Recycled plastic used: 35–40 %

Guarantee

- 2 year worldwide guarantee

Crease removal

- Vertical Steam

Green efficiency

- Energy saving*: Up to 30% energy savings*

Highlights

Compact and convenient

Thanks to its compact size it's light and easy to handle as you iron your clothes. It even fits on your ironing board. But don't think smaller means less powerful. Thanks to our exclusive ProVelocity technology, we've made powerful steam generators that are lightweight and more compact than ever.

Powerful steam

Strong, continuous steam for effective crease removal of even the most stubborn creases on the thickest fabrics.

No temperature setting needed

Iron everything from silk to jeans without adjusting the temperature and no burns guaranteed*. Thanks to OptimalTEMP, no dial or settings are needed. So there's no more pre-sorting the laundry or waiting for the iron to heat up and cool down. You're ready for any fabric, anytime.

SteamGlide Advanced soleplate

Our superior SteamGlide Advanced soleplate delivers smooth gliding performance on any fabric. Its stainless steel base is twice as hard as aluminium, and our patented 6-layer coating with its advanced titanium layer effortlessly glides on any fabric for the fastest results.

1.8 l detachable water tank

The 1.8-litre transparent water tank gives you up to 1.5 hours of continuous use. When the water tank is empty, you will be reminded by the indicator light to refill at any time, which you can easily do under the tap through the large filling door.

Auto-shut off

Auto-shut off to save energy and for peace of mind

Easy descaling

It's easy to maintain your steam generator with Smart Calc Clean, our built-in descaling system. It will remind you when it's time to descale and includes a container to make descaling easy and safe. Since it is reusable you will save money and never need to buy extra cartridges.

Safety carry lock

Lock your iron securely to the base station for easy carrying around the house and to reduce the risk of accidentally touching the hot soleplate.



Issue date 2022-07-25

Version: 8.8.1

EAN: 08 72038 90049 02

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* **On all ironable garments

*** Up to 20% energy savings based on IEC 603311, compared to GC6742