

Philips PerfectCare Expert
Plus
Steam generator iron

Max 7.5 bar pressure

Up to 520g steam boost
1.8L detachable watertank
Ultra-light iron

GC8962/40



Incredibly light and powerful

for speed and comfort

PerfectCare Expert Plus is designed for your comfort and convenience. Ultra-light and easy to handle, but still with powerful steam to achieve great results faster. With OptimalTEMP technology to guarantee no burns on all ironable garments.

No temperature setting needed, guaranteed no burn

- OptimalTEMP technology, no temperature settings required
- No burns – guaranteed

Fast ironing with continuous powerful steam

- Save energy with ECO mode
- Powerful steam for ultimate crease removal
- Easy and efficient descaling system for lasting performance
- SteamGlide Advanced soleplate, ultimate gliding & durability

Extra convenience

- Ultra-light weight and comfortable iron to handle
- Powerful yet silent steam
- Large 1.8L detachable water tank for easy refilling
- Carry lock for safe and easy transport
- Automatic shut off when iron is left unattended

PHILIPS

Steam generator iron
Max 7.5 bar pressure Up to 520g steam boost, 1.8L detachable watertank, Ultra-light iron

GC8962/40

Highlights

No temperature setting needed



Iron everything from silk to jeans without adjusting the temperature. Thanks to OptimalTEMP, no dial or settings are needed. So there's no more pre-sorting the laundry, or waiting for the iron to heat up and cool down. You're ready for any fabric, anytime.

No burns – guaranteed



Thanks to OptimalTEMP technology, we guarantee this iron will never cause burns to any ironable fabric. You can even leave it resting face down on your clothes or ironing board. No burns, no shine. Guaranteed.

Ultra-powerful steam



Strong, continuous steam tackles even the thickest fabrics with ease. Watch stubborn

creases melt away with an extra steam boost just where you need it. This extra steam is perfect for vertical steaming to refresh clothes and curtains, too.

Ultra-light weight iron



The iron is amazingly light and comfortable to handle, gliding easily and reducing wrist strain. Its minimal weight also makes it easy and effective for vertical steaming of curtains and hanging clothes.

SteamGlide Advanced soleplate



Our superior SteamGlide Advanced soleplate delivers smooth gliding performance on any fabric. Its stainless steel base is twice as hard as a aluminum, and our patented 6-layer coating with its advanced titanium layer effortlessly glides on any fabric for the fastest results.

Easy De-Calc



Regular descaling protects your iron, extends its lifetime, and ensures the best steam performance. Our exclusive Easy De-Calc system collects limescale continuously with an indicator light to tell you when it needs emptying. Simply remove the plug and let the water and scale particles flow out.

Silent steam technology



Silencing filters minimize steam noise so our powerful steam won't overpower the sounds of television, music or family.

1.8L detachable water tank



1.8-liter transparent tank gives you up to 2 hours of continuous use. When the water tank is empty, you will be reminded by the indicator light and you can refill easily at any time under the tap through the large filling door.

Specifications

Storage

- Carry lock: For transportation and safety
- Hose storage: Hose storage compartment

Easy to use

- Safe on all ironable fabrics: Even delicates like silk
- Water tank capacity: 1800 ml
- Soleplate gliding performance: 5 stars
- Safety auto off
- Soleplate name: SteamGlide Advanced
- Detachable water tank
- Low water alert
- Refill any time during use
- Tap water suitable
- Power cord length: 1.65 m
- Hose length: 1.7 m
- Precision steam tip
- Ready to use: Light indicator
- Soleplate scratch resistance: 5 stars

Guarantee

- 2 year worldwide guarantee

Technology

- OptimalTEMP technology
- Cyclonic steam chamber
- For all ironable fabrics
- No burns
- No temperature settings needed
- Silent steam Technology

Fast crease removal

- Pressure: Max 7.5 bar
- Power: Max 2100 W
- Continuous steam: Up to 120 g/min
- Steam boost: Up to 520 g
- Voltage: 220 - 240 V
- Vertical steam
- Ready to use: 2 minute(s)
- Steam-on-demand

Green efficiency

- Energy saving mode
- Energy saving*: 45 %
- Product packaging: 100% recycable
- User manual: 100% recycled paper

Scale management

- Descaling and cleaning: Easy De-calc
- Descaling reminder: Light

Size and weight

- Weight of iron: 0.8 kg
- Packaging dimensions (WxHxL): 31 x 31 x 47 cm
- Product dimensions (WxHxL): 23.9 x 26.9 x 42.6 cm
- Total weight with packaging: 5.5 kg
- Weight of iron + base: 4 kg



Issue date 2023-09-05

Version: 1.1.2

EAN: 87 10103 92072 4

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Up to 30% energy saving with ECO mode compared to default mode
based on IEC 60311