



**Saeco Exprelia Evo
Super-automatic
espresso machine**

- Brews 7 coffee varieties
- Integrated milk jug & frother
- Stainless steel
- 5 step adjustable grinder



HD8857/01

Perfect, hot, clean.

That's the premium milk froth experience

Only the Saeco Exprelia EVO espresso machine delivers the ultimate milk experience thanks to the new H2 Technology Milk Carafe and the full bean to cup customization

Authentic Italian coffee perfection

- Coffee without burnt taste thanks to 100% ceramic grinders
- Perfect froth thanks to the dual chamber milk carafe
- Milk specialties without the wait thanks to a double boiler

Ease of cleaning and maintaining

- Always a clean machine thanks to auto-clean and descaling
- Easy cleaning thanks to removable brewing group

Ease of cleaning and maintaining

- Hygienic milk frothing thanks to automated dual cleaning
- Cutting-edge design with stainless steel finish

Set the beverages to suit your taste

- Play with the coffee's richness with our adjustable grinders
- Boost coffee crema and body

 **Saeco**



Highlights

Stainless steel



The cutting-edge design of your Saeco espresso machine is rounded off by the stainless steel finish. The stainless steel provides a high quality look and will be a highlight on your kitchen counter tops. It also gives greater resistance for a long-lasting performance.

100% ceramic grinders



This espresso machine is equipped 100% ceramic grinders. Saeco uses ceramic grinders because of their consistent grind without overheating the coffee bean for an impeccable espresso. Ceramic also ensures long-lasting performance and a totally silent operation.

Dual chamber milk carafe



Enjoy your milk specialties fully automated with the patented milk carafe with dual chamber technology. Simply pour milk into the carafe, plug it into the machine and select your coffee drink. With the dual chamber technology you will always enjoy professional coffee drinks with dense, long-lasting milk froth at the ideal temperature from a constant splash-free flow of milk.

8 step adjustable grinders



Different coffee blends require different levels of granularity for the full flavor to unfold. The grind granularity of this espresso machine can be adjusted in 8 settings, from the finest grind, for a full bodied espresso, to the coarsest, for a lighter coffee.

Saves your coffee settings



You will always get a perfect cup of espresso brewed just for you, according to your personal preference, thanks to our innovative memo function to adjust the coffee length, strength and temperature. Enjoy a superb coffee drink in your favorite cup with just the press of a button.

Removable brewing group



The brewing group, a Saeco invention, is the heart of our espresso machines, ensuring automation. The brewing group is, depending on the model, easily accessible from the front or side. It can be removed effortlessly for easily cleaning by rinsing under the tap ensuring maximum hygiene.

Super-automatic espresso machine
Brews 7 coffee varieties Integrated milk jug & frother, Stainless steel, 5 step adjustable grinder

HD8857/01

Specifications

Perfect Espresso

- Espresso technology: Saeco adapting system, Aroma-system: pre-brewing, SBS: creme adaptor

Multi-Beverage

- Milk Variations: Integrated auto milk function, Milk quantity selector, Removable milk carafe

Energy saving

- Energy saving: Automatic stand-by

Technical data

- Voltage: 230 V
- Power: 1400 W
- Pump Pressure: 15 bar
- Frequency: 50 Hz

Technical specifications

- Cord length: 80 cm
- Supported coffee types: Ground coffee, Whole coffee beans
- Boiler material: Stainless steel (Inox)
- Voltage: 230 V
- Power: 1400 W
- Country of origin: Designed in Italy, Made in Italy
- Frequency: 50 Hz
- Water pressure in pump: 15 bar (perfect espresso)
- Number of water boilers: 1 boiler
- Removable brewing group

Design

- Colour: Stainless steel
- Materials and finishing: Stainless steel

Weight and dimensions

- Waste container capacity: 11 servings
- Weight: 14,2 kg
- Product weight: 16.1 kg
- Product dimensions (L x D x H): 245 x 420 x 360 mm
- Coffee bean capacity: 300 g
- Maximum cup height: 150 mm
- Milk carafe capacity: 0.5 L
- Water tank capacity: 1.5 L

Easy to use

- Usage: Adjustable coffee dispenser, Bypass for grinded coffee, Frontal access to all function, Instant steam (2 boilers), Removable brewing group, Removable watertank
- Cleaning and maintenance: Automatic coffee circuit rinse, Automatic milk circuit rinse, Descaling cycle

Service

- 2-year worldwide guarantee

Sustainability

- Automatic Stand-by Option



Issue date 2023-08-21

Version: 2.2.1

EAN: 87 10103 58442 1

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com