



**Saeco Moltio
Super-automatic
espresso machine**

- Brews 7 coffee varieties
- Classic Milk Frother
- Black
- 5-step adjustable grinder



HD8767/01

Every moment deserves its coffee flavour

Changing beans is now one click away

The Moltio espresso machine, a unique masterpiece crafted to offer a tailored taste experience. Thanks to our exclusive bean switcher, preparing the right coffee that always matches your mood and the occasion will be as easy as a click

A variety of coffees customised to your taste

- The strength selection remembers just how strong you like it

Advanced technology designed for coffee perfection

- Velvety milk foam with the Classic Milk Frother

High comfort is part of the experience

- The fully removable brewing group can be cleaned in no time

Advanced technology designed for coffee perfection

- Extract maximum flavour with the 100% ceramic grinders
- Fine-tune the coffee's richness with 5 grinder settings

 **Saeco**



Highlights

5-steps adjustable grinders



When it comes to the fineness of the grind, this machine never fails to satisfy. Different coffee blends require different levels of granularity for the full flavour to be released. So the grind granularity of this machine has five adjustable settings — from the finest grind for a full-bodied espresso, to the coarsest for a lighter coffee.

100% Ceramic grinders



The robust 100% ceramic grinders guarantee a moment of pure coffee indulgence for years to come. The ceramic material creates the ideal grind, which allows the water to flow through steadily, extracting the purest essence of the beans. And unlike other 'regular' grinders, the ceramic material prevents the coffee from overheating and tasting burnt.

Removable brewing group



Efficiency and ease of use were key inspirations when Saeco invented the first brewing group 30 years ago. And to this day, it still proves to be an inspired, resolute piece of technology. As always, it's so simple to clean — just remove it and wash it under the tap for a few seconds, then re-insert it just as easily.

Memo Function



Once you've chosen your ideal strength from the 5 different settings, you can easily save it with the Memo Function, as well your desired length and temperature. Then every cup in the future will be customised exactly to your taste. You'll never have to remind it again, unlike the local barista.

Classic Milk Frother



The Classic Milk Frother is for those who love to assume the role of master craftsman, and it's just easy. Within seconds you can create a rich, silky layer of foam — the crowning glory of your coffee.

Specifications

Weight and dimensions

- Dimensions of product (W x D x H): 256 x 470 x 350 mm

Country of origin

- Made in: Europe

Technical specifications

- Voltage: 230 V
- Capacity bean container: 290 g
- Cord length: 0.8 m
- Frequency: 50 Hz
- Capacity water tank: 1.9 L
- Capacity waste container: 15 serv
- Pump pressure: 15 bar
- Max. cup height: 142 mm
- Water boilers: 1

General specifications

- Suitable for: Whole coffee beans, ground coffee powder
- Cups at the same time: 2
- Ease of cleaning and maintenance: Automatic de-scaling cycle, Automatic rinse cycle, AquaClean filter compatible, Optional Brita water filter, Removable brewing group
- Ease of use and comfort: Removable spout, Automatic shut-off, Display, Automatic stand-by
- Type of boiler: Quick-heat boiler
- Special functions: Steam option, Manual milk frother Pannarello, Pre-brewing, Hot water option, Ceramic grinder
- Type of carafe: Basic carafe
- Type of display: LCD
- Coffee drinks: Espresso, Cappuccino, hot water, Café Crème, frothed milk, Espresso Macchiato, Latte Macchiato

Design

- Colour: Black and Metal

Weight and dimensions

- Weight of product: 8.5 kg

Finishing

- Material of main body: Plastic
- Material boiler: Stainless steel (Inox)
- Material water tank: Plastic
- Material pannarello: Stainless steel

Service

- 2 year guarantee

Sustainability

- Power consumption brewing: 1850 W